Original		Replacement	
	Power		Power
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TRACKING/V-LOCK −	Tracking/V-Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
	Vol -	VOL −	Vol -
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Prog/Check+	SHIFT + TV 1	Shift + 1
+ DATE	Green	APP REPEAT	Green / APP / Repeat
+ DATE	Date+	SHIFT + DVD 2	Shift + 2
+ ON	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+ ON	On+	SHIFT + CD-STB 3	Shift + 3
+ OFF	Blue	Prime Video RANDOM	Blue / Prime Video / Random
+ OFF	Off +	SHIFT + AUX-HDD 7	Shift + 7
PROG./CHECK	Prog/Check-	SHIFT + VIDEO 4	Shift + 4
DATE −	Date-	SHIFT + TAPE 5	Shift + 5
ON −	On-	SHIFT + TUNER 6	Shift + 6
OFF −	Off -	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--

Original		Replacement	
	Power		Power
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Tracking/V-Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
	Vol -	VOL −	Vol -
REPLAY	Replay	SHIFT + SLOW ▶	Shift + Play /
OSD/DISPLAY	OSD/Display	MEDIA DISPLAY	Display / Media
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
SHOW VIEW	Showview	LIST SMART	Smart / List
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
INDEX ⏮	I<< Index	PRESET- ⏮	I<< / Preset-
INDEX ⏭	Index >>I	PRESET+ ⏭	>>I / Preset+
REC	Rec	REC MODE	Rec / Rec Mode
⏸/▶	Pause/Step	STEP-FREEZE ⏸	Pause / Step / Freeze
MENU	Menu	HOME MENU	Menu / Home
OK	OK	OK	OK
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
◀◀	<<	TUNE- ◀◀	<< / Tune-
◀	Left	◀	Left
▷	Play	SLOW ▶	Play / Slow
▷	Up	▲	Up

Original	Replacement
>>	>> / Tune+
Right	Right
Stop	Stop / Hold
Down	Down
Prog+/ Red	Shift + 1
Date+/ Green	Shift + 2
On+/ Yellow	Shift + 3
Off+/ Blue	Shift + 7
Prog-	Shift + 4
Date-	Shift + 5
On-	Shift + 6
Off-	Shift + Guide / EPG / -/--
Prog/ Check	TV/ Radio /
Cancel	Shift + Exit / Cancel / Clear
Nothing 1	Green / APP / Repeat
Timer Rec	Sleep / Timer
Reset	Back / Return

Original	Replacement
Nothing 2	Yellow / YouTube / Repeat
VPS/ PDC	Setup / OPT /
AV Link	Shift + AV / Input / RDS
Tv Aspect	Picture / Format
Nothing 3	Blue / Prime Video / Random