Original		Replacement	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
VOL	Vol + Tv	VOL	Vol +
CH	CH+ TV	SHIFT + CH PAGE	Shift + CH+ /
INPUT AV	AV Input Tv	RDS AV INPUT	AV / Input / RDS
VOL	Vol - Tv	VOL	Vol -
CH	CH- Tv	SHIFT + CH PAGE	Shift + CH- /
1	1	1	1
2abc	2	2	2
3def	3	3	3
REC	Rec	REC MODE	Rec / Rec Mode
4ghi	4	4	4
5jkl	5	5	5
6mno	6	6	6
PAGE CH	CH+	CH PAGE	CH+ / Page+
7pqrs	7	7	7
8tuv	8	8	8

Original		Replacement	
9wxyz	9	BLUETOOTH 9	9
CH	CH-	CH PAGE	CH- / Page-
LAST VIEW	Last View	SHIFT + RETURN BACK	Shift + Back / Return
0	0	HDMI - SAT 0	0
DRIVE SELECT	Drive Select	MEDIA DISPLAY	Display / Media
PROG/CHECK	Prog/Check	HOME MENU	Menu / Home
-10s	-10s	PC FAV MARKER	Fav / Marker / PC
+60s	+60s	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
INTERNET	Internet	LIST SMART	Smart / List
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	<<	TUNE-	<< / Tune-
x1.3	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
	Stop	HOLD	Stop / Hold

Original		Replacement		Original		Replacement	
STATUS	i / Status	ANGLE INFO	Info / Angle	DELETE	Delete	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--	TEXT	Text	GOTO TEXT	Text / Goto
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	STTL	STTL	EQ SUBTITLE	Subtitle / EQ
VIDEO MENU	Video Menu	SHIFT + VIDEO 4	Shift + 4				
	Up		Up				
FUNCTION MENU	Function Menu	TOP MENU D.MENU	D.Menu / Top				
	Left		Left				
OK	OK	OK	OK				
	Right		Right				
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /				
	Down		Down				
RETURN	Return	RETURN BACK	Back / Return				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				