Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
TIMER SLEEP	Sleep/Timer	HOME SMART	Smart
DISPLAY CLOCK	Clock/Display	ECO 3D	3D
INFO. RDS	RDS/Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
PROG	Prog	PROG SLEEP	Sleep
DBB	DBB	CLEAR EXIT	Exit
	Play/Pause	PLAY MODE	Play
	Stop		Stop
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	CH −	Ch -
OK	OK	OK	Ok
	Up		Up
	Down		Down

Original		Replacement	
	>>I		>>I
	>>I		Right
	I <<		I <<
	I <<		Left

Original		Replacement	
MUTE	Mute	MUTE	Mute
▶II	Play/Pause	PLAY MODE ▶	Play
⏻	Power	⏻	Power
OK	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
⏭	>>I	⏭	>>I
⏭	>>I	▶	Right
⏮	I <<	⏮	I <<
⏮	I <<	◀	Left
PROG	Prog	PROG SLEEP	Sleep
■	Stop	■	Stop
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	CH −	Ch -
SCAN	Scan	RETURN BACK	Back

Original		Replacement	
TIMER SLEEP	Sleep/Timer	HOME SMART	Smart
DISPLAY CLOCK	Clock/Display	ECO 3D	3D
INFO. RDS	RDS/Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
DBB	DBB	CLEAR EXIT	Exit

Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
TIMER SLEEP	Sleep/Timer	HOME SMART	Smart
DISPLAY CLOCK	Clock/Display	ECO 3D	3D
INFO. RDS	RDS/Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
DBB	DBB	CLEAR EXIT	Exit
SCAN	Scan	RETURN BACK	Back
PROG	Prog	PROG SLEEP	Sleep
	Stop		Stop
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
OK	OK	OK	Ok
	Down		Down
	Up		Up
	>>I		>>I

Original		Replacement	
	>>I		Right
	I <<		I <<
	I <<		Left

Original		Replacement	
	Power		Power
	Mute		Mute
	Sleep/Timer		Smart
	Clock/Display		3D
	RDS/Info		Info
	DBB		Exit
	Stop		Stop
	Vol +		Vol +
	Vol -		Vol -

Original	Replacement