# Mandis shop

Philips CRP63201

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Vol + | Vol + |
| Audio Source | Red | Vol - | Vol - |
| Play | Play | Treble | Ch + |
| Pause | Pause | Bass | Ch - |
| Radio | TV/R | Up | Up |
| USB | Yellow | Down | Down |
| MP3 Link | Blue | Right / >> | Right |
| Disc | Smart | Left / << | Left |
| Audio | Dual | OK | Ok |
| Options | Options | 1 | 1 |
| Menu/ Back | Menu | 2 | 2 |
| [i] / Info | Info | 3 | 3 |
| Stop | Stop | 4 | 4 |
| Mute | Mute | 5 | 5 |
| >I | >>I | 6 | 6 |
| I < | I << | 7 | 7 |
| Surround | Format | 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| SUBTITLE | Subtitle | AD SUBT | Subt |
| AUDIO SYNC | Audio Sync | APP MEDIA | Media |
| REPEAT PROGRAM | Repeat / Program | PROG SLEEP | Sleep |
| ZOOM | Zoom | ZOOM ⏏ | Eject |
| REPEAT A-B | A-B/ Repeat | REPEAT TEXT | Text |
| SOUND | Sound | SHIFT + SOUND DUAL | Shift + Dual |
| ▲ | Up Radio | SHIFT + ▲ | Shift + Up |
| ▼ | Down Radio | SHIFT + ▼ | Shift + Down |
| ▶ ▶▶ | Right / >> Radio | SHIFT + ▶ | Shift + Right |
| ◀◀ ◀ | Left / << Radio | SHIFT + ◀ | Shift + Left |
| OK | OK Radio | SHIFT + OK | Shift + Ok |
| ▶I | >I Radio | ≫ | >> |
| I◀ | I< Radio | ≪ | << |
| 1 | 1 Radio | SHIFT + 1 | Shift + 1 |
| 2 | 2 Radio | SHIFT + 2 | Shift + 2 |

| Original | | Replacement | |
|---|---|---|---|
| 3 | 3 Radio | SHIFT + 3 | Shift + 3 |
| 4 | 4 Radio | SHIFT + 4 | Shift + 4 |
| 5 | 5 Radio | SHIFT + 5 | Shift + 5 |
| 6 | 6 Radio | SHIFT + 6 | Shift + 6 |
| 7 | 7 Radio | SHIFT + 7 | Shift + 7 |
| 8 | 8 Radio | SHIFT + 8 | Shift + 8 |
| 9 | 9 Radio | SHIFT + 9 | Shift + 9 |
| 0 | 0 Radio | SHIFT + 0 | Shift + 0 |