| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Mute | Mute / Dimmer |
| Red/Demo | Red / Netflix / Search | P- | CH- / Page- |
| Green | Green / APP / Repeat | 1 | 1 |
| Yellow | Yellow / YouTube / Repeat | 2 | 2 |
| Blue | Blue / Prime Video / Random | 3 | 3 |
| Option | Setup / OPT / | 4 | 4 |
| [ I ] | Guide / EPG / -/-- | 5 | 5 |
| Up | Up | 6 | 6 |
| Left | Left | 7 | 7 |
| OK | OK | 8 | 8 |
| Right | Right | 9 | 9 |
| Down | Down | AV | AV / Input / RDS |
| Menu/Browse | Menu / Home | 0 | 0 |
| [ ≡] | Text / Goto | P<P | P<P |
| Vol + | Vol + | << | << / Tune- |
| P+ | CH+ / Page+ | Stop/Cancel | Exit / Cancel / Clear |
| Vol - | Vol - | Stop/Cancel | Stop / Hold |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| >> | TUNE+ >> / Tune+ | | |
| Rec | REC MODE Rec / Rec Mode | | |
| [i+] | ANGLE INFO Info / Angle | | |
| [1I2] | MEDIA DISPLAY Display / Media | | |
| FAV | PC FAV MARKER Fav / Marker / PC | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|---|---|
| Power | Power |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |
| Menu | Menu / Home |
| P+ | CH+ / Page+ |
| P- | CH- / Page- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |

| Original | Replacement |
|---|---|
| 9 | 9 |
| 0 | 0 |
| P↔P | Fav / Marker / PC |
| << | << / Tune- |
| Stop/Cancel | Stop / Hold |
| Play | Play / Slow |
| >> | >> / Tune+ |
| Info | Info / Angle |
| Subtitle | Subtitle / EQ |
| Back | Back / Return |
| Pause | Pause / Step / Freeze |
| | |
| | |
| | |
| | |
| | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Red/Demo | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | Guide | | Guide / EPG / -/-- |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |
| | Menu | | Menu / Home |
| | Teletext | | Text / Goto |
| | P+ | | CH+ / Page+ |
| | P- | | CH- / Page- |
| | 1 | | 1 |
| | 2 | | 2 |

| Original | | Replacement | |
|---|---|---|---|
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | P↔P | | Fav / Marker / PC |
| | << | | << / Tune- |
| | Stop/Cancel | | Stop / Hold |
| | Play | | Play / Slow |
| | >> | | >> / Tune+ |
| | Rec | | Rec / Rec Mode |
| | Info | | Info / Angle |
| | [1|2] | | Zoom / Size |
| | Subtitle | | Subtitle / EQ |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Back | RETURN BACK Back / Return | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |