Mandis shop

Pioneer PWW1175

Original		Replacement	
	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
PURE AUDIO	Pure Audio	SOUND DUAL	Dual
DIMMER	Dimmer	APP MEDIA	Media
	Play	PLAY MODE	Play
	Stop		Stop
	Pause		Pause
	>>		>>
	<<		<<
	I <<		I <<
	>>I		>>I
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

Original		Replacement	
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	CLEAR EXIT	Exit
ENTER	Enter	OK	Ok
SACD SETUP	SACD Setup	TOP MENU MENU	Menu
LEGATO LINK	Legato Lynk	HOME SMART	Smart
REPEAT	Repeat	REPEAT TEXT	Text
PROGRAM	Program	PROG SLEEP	Sleep
RANDOM	Random	GUIDE	Guide
TIME	Time	TIMER AV	AV

https://remotecontrols.com/Pioneer/1585-243-replacement-remote-control-for-Pioneer-PWW1175.htm