Original	Replacement
Power	Power
Input 1	SHIFT + TV 1 — Shift + 1
Input 2	SHIFT + DVD 2 — Shift + 2
Input 3	SHIFT + CD-STB 3 — Shift + 3
Input 4	SHIFT + VIDEO 4 — Shift + 4
Input 5	SHIFT + TAPE 5 — Shift + 5
PC	SHIFT + PC FAV MARKER — Shift + Fav / Marker / PC
HMG	SHIFT + TUNER 6 — Shift + 6
[i+]/Timer/Inf	TIMER SLEEP — Sleep / Timer
[i+]/Timer/Inf	ANGLE INFO — Info / Angle
[ ]	SHIFT + NETFLIX SEARCH — Shift + Red / Netflix /
[←]	SHIFT + YouTube REPEAT A-B — Shift + Yellow / YouTube /
[↔]	SHIFT + APP REPEAT — Shift + Green / APP /
HDMI CTRL	FORMAT PICTURE — Picture / Format
1	TV 1 — 1
2	DVD 2 — 2
3	CD-STB 3 — 3

Original	Replacement
4	VIDEO 4 — 4
5	TAPE 5 — 5
6	TUNER 6 — 6
7	AUX-HDD 7 — 7
8	USB 8 — 8
9	BLUETOOTH 9 — 9
EPG DVD TOPMENU/GUIDE — EPG/DVD Top Menu/Guide	TOP MENU D.MENU — D. Menu / Top
EPG DVD TOPMENU/GUIDE — EPG/DVD Top Menu/Guide	-/-- GUIDE EPG — Guide / EPG / -/--
0	HDMI-SAT 0 — 0
TV/DTV/SAT — TV/DTV/SAT	RDS AV INPUT — AV / Input / RDS
P+	CH PAGE + — CH+ / Page+
CH RETURN — CH return	PC FAV MARKER — Fav / Marker / PC
Vol +	VOL + — Vol +
P-	CH PAGE − — CH- / Page-
Mute	DIMMER MUTE — Mute / Dimmer
Vol -	VOL − — Vol -
EXIT — Exit	CLEAR EXIT CANCEL — Exit / Cancel / Clear

Original	Replacement	Original	Replacement
Up	Up	[. . .]	Subtitle / EQ
Tools	Setup / OPT /	>>I	>>I / Preset+
Left	Left	[≡?]	Shift + Display / Media
Enter	OK	<<	<< / Tune-
Right	Right	[≡i]	Shift + Smart / List
Home	Menu / Home	>>	>> / Tune+
Down	Down	[≡]	Text / Goto
Return	Back / Return	I-II	I-II
Red	Red / Netflix / Search	[➖] DVD/ [+]	Smart / List
Rec	Rec / Rec Mode	[<>] / HDD	Display / Media
Green	Green / APP / Repeat		
Pause	Pause / Step / Freeze		
Yellow	Yellow / YouTube / Repeat		
Stop	Stop / Hold		
Blue	Blue / Prime Video / Random		
Play	Play / Slow		
I <<	I << / Preset-		

Original		Replacement	
TV	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EPG DVD TOPMENU/ GUIDE	EPG/ DVD Top Menu/ Gui de	-/-- GUIDE EPG	Gui de / EPG / -/--
EPG DVD TOPMENU/ GUIDE	EPG/ DVD Top Menu/ Gui de	TOP MENU D.MENU	D. Menu / Top
0	0	HDMI - SAT 0	0
+	Vol + Tv	+ VOL	Vol +
	Mut e Tv	DIMMER MUTE	Mut e / Di mmer
−	Vol - Tv	VOL −	Vol -
	Up		Up

Original		Replacement	
	Lef t		Lef t
ENTER	Ent er	OK	OK
	Ri ght		Ri ght
HOME MENU MENU	Menu/ Home	HOME MENU	Menu / Home
	Down		Down
RETURN	Ret ur n	RETURN BACK	Back / Ret ur n
	Pause	STEP - FREEZE	Pause / St ep / Fr eeze
	St op	HOLD	St op / Hol d
	Pl ay	SLOW	Pl ay / Sl ow
	I <<	PRESET-	I << / Pr eset -
	>>I	PRESET+	>>I / Pr eset +
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+

Original		Replacement	
TV	Power		Power
INFO	[i +] / Timer / Inf	ANGLE INFO	Info / Angle
INFO	[i +] / Timer / Inf	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EPG DVD TOPMENU/GUIDE	EPG / DVD Top Menu / Guide	-/-- GUIDE EPG	Guide / EPG / -/--
EPG DVD TOPMENU/GUIDE	EPG / DVD Top Menu / Guide	TOP MENU D.MENU	D. Menu / Top
0	0	HDMI - SAT 0	0
+ P	P+	+ CH PAGE	CH+ / Page+
+	Vol + Tv	+ VOL	Vol +

Original		Replacement	
P –	P-	CH PAGE –	CH- / Page-
	Mute Tv	DIMMER MUTE	Mute / Dimmer
–	Vol - Tv	VOL –	Vol -
EXIT	X / Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
ENTER	OK	OK	OK
	Right		Right
HOME MENU MENU	Menu / Home	HOME MENU	Menu / Home
	Down		Down
RETURN	Return	RETURN BACK	Back / Return

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
P+	CH+ / Page+
Vol + Tv	Vol +
P-	CH- / Page-
Mute Tv	Mute / Dimmer
Vol - Tv	Vol -
Rec	Rec / Rec Mode

Original	Replacement
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Play	Play / Slow
I<<	I<< / Preset-
>>I	>>I / Preset+