Mandis shop

Sharp RRMCGA024SJSA

Original		Replacement	
	On/Standby		Power
	Timer	TIMER AV	AV
	Clock	ECO 3D	3D
	Memory	OK	Ok
	Clear	CLEAR EXIT	Exit
	Random/Repeat	REPEAT TEXT	Text
	Sleep	PROG SLEEP	Sleep
	Display	DISPLAY INFO	Info
	CD	C	Yellow
	Tuner/Band	B	Green
	Tape	A	Red
	Video/AUX	D	Blue
	>>/Tuning Up	>>	>>
	<</Tuning	<<	<<
	>>I/Preset Up	>>I	>>I
	I<</Preset	I<<	I<<
	Play	PLAY MODE	Play

Original		Replacement	
	Stop		Stop
	Pause		Pause
	1/Memory	1	1
	2/Clear	2	2
	3/Random/Repe	3	3
	4/Clock	4	4
	5/Timer	5	5
	6/Sleep	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
	+10	GUIDE	Guide
	Shift	APP MEDIA	Media
	Treble/Bass	HOME SMART	Smart
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -