Original		Replacement		Original		Replacement	
TV I/⏻ STANDBY	Power	⏻	Power	8	8	8	8
AV I/⏻ SYSTEM	Power AV	SHIFT + ⏻	Shift + Power	9	9	9	9
AUTO CAL	Auto Cal	HOME SMART	Smart	0/10	0/10	0	0
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep	>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
MD/TAPE	MD-TAPE	APP MEDIA	Media	DUAL MONO	Dual Mono	SOUND DUAL	Dual
AMP MENU	AMP MENU	TOP MENU MENU	Menu	FM MODE	FM Mode	SEARCH TV/R	TV/R
2CH	2CH	A	Red	DISPLAY	Display	DISPLAY INFO	Info
A.F.D.	A.F.D.	B	Green		Up AMP Menu	▲	Up
MOVIE	Movie	C	Yellow		Down AMP	▼	Down
MUSIC	Music	D	Blue		Right AMP Menu	▶	Right
1	1	1	1		Left AMP Menu	◀	Left
2	2	2	2		OK MD/Tape	SHIFT + OK	Shift + Ok
3	3	3	3		OK AMP Menu	OK	Ok
4	4	4	4	TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
5	5	5	5	–	Vol -	VOL –	Vol -
6	6	6	6	MUTING	Muting	MUTE	Mute
7	7	7	7	TV CH – PRESET –	I<<</Preset-	<<	I<<

Original		Replacement		Original	Replacement
TV CH + PRESET +	>>I / Preset +	>>I	>>I		
TUNING −	<<I Tuning-	<<	<<		
	Play	PLAY MODE ▶	Play		
TUNING +	>>I Tuning+	>>	>>		
	Pause	❚❚	Pause		
	Stop	■	Stop		

Original		Replacement	
	Power		Power
	Power AV	SHIFT +	Shift + Power
	Auto Cal	HOME SMART	Smart
	Sleep	PROG SLEEP	Sleep
2CH	2CH	A	Red
A.F.D.	A. F. D.	B	Green
MOVIE	Movie	C	Yellow
MUSIC	Music	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0/10	0/10	0	0
>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
MEMORY ENTER	Enter/Memory	FAV PRE-CH	Pre Ch
MENU	Menu	TOP MENU MENU	Menu
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
RETURN/EXIT	Return/Exit	CLEAR EXIT	Exit
TOOLS	Tools	SETTINGS OPT	Options
DISPLAY	Display	DISPLAY INFO	Info
D.TUNING D.SKIP	D. Tuning/D. Skip	PICTURE FORMAT	Format
FM MODE	FM Mode	SEARCH TV/R	TV/R
DUAL MONO	Dual Mono	SOUND DUAL	Dual
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	OK	OK	Ok
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
TUNING –	<<Tuning-		<<
TUNING +	>>Tuning+		>>
TV CH + PRESET +	>>I / Preset +		>>I
TV CH – PRESET –	I<< / Preset -		I<<
REPLAY	← / Replay	CH –	Ch -
ADVANCE	· → / Advance	+ CH	Ch +
DVD	DVD	APP MEDIA	Media
D.TUNING D.SKIP	D. Tuning/ D. Skip Tuner	ECO 3D	3D
TUNER	Tuner	SHIFT + APP MEDIA	Shift + Media
MEMORY ENTER	Enter / Memory	SHIFT + FAV PRE-CH	Shift + Pre Ch
1	1 Tuner	SHIFT + 1	Shift + 1
2	2 Tuner	SHIFT + 2	Shift + 2

Original		Replacement	
3	3 Tuner	SHIFT + 3	Shift + 3
4	4 Tuner	SHIFT + 4	Shift + 4
5	5 Tuner	SHIFT + 5	Shift + 5
6	6 Tuner	SHIFT + 6	Shift + 6
7	7 Tuner	SHIFT + 7	Shift + 7
8	8 Tuner	SHIFT + 8	Shift + 8
9	9 Tuner	SHIFT + 9	Shift + 9
0/10	0/10 Tuner	SHIFT + 0	Shift + 0
DISPLAY	Display Tuner	SHIFT + DISPLAY INFO	Shift + Info
	OK Tuner	SHIFT + OK	Shift + Ok
	Up Tuner	SHIFT +	Shift + Up
	Down Tuner	SHIFT +	Shift + Down
	Right Tuner	SHIFT +	Shift + Right
	Left Tuner	SHIFT +	Shift + Left
TUNING –	<<Tuning- Tuner	SHIFT +	Shift + <<
TUNING +	>>Tuning+	SHIFT +	Shift + >>
TV CH – PRESET –	I<< / Preset - / Tv CH- Tuner	SHIFT +	Shift + I<<

Original	Replacement	Original	Replacement
TV CH + PRESET + >>I / Preset +/ Tv CH+ Tuner	SHIFT + >>I Shift + >>I		

Original		Replacement	
	Power		Power
	Play	PLAY MODE	Play
	Stop		Stop
AUTO CAL	Auto Cal	HOME SMART	Smart
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0
>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
	OK	OK	Ok

Original		Replacement	
MEMORY ENTER	Enter/Memory	FAV PRE-CH	Pre Ch
MENU	Menu	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
DUAL MONO	Dual Mono	SOUND DUAL	Dual
FM MODE	FM Mode	PICTURE FORMAT	Format
2CH	2CH	A	Red
A.F.D.	A.F.D.	B	Green
MOVIE	Movie	C	Yellow
MUSIC	Music	D	Blue
	Pause		Pause

Original		Replacement		Original	Replacement
TUNING +	>>/ Tuning+	>>			
TUNING –	<</ Tuning-	<<			
TV CH + PRESET +	>>I / Preset +	>>I			
TV CH – PRESET –	I <</ Preset -	I <<			
REPLAY	← / Replay	CH –	Ch -		
ADVANCE	· →/ Advance	+ CH	Ch +		
VIDEO 3	Video 3	SHIFT + APP MEDIA	Shift + Media		
VIDEO 1	Video 1	APP MEDIA	Media		
AV I/⏻ SYSTEM	Power AV	TIMER AV	AV		
TV I/⏻ STANDBY	Tv Power	SHIFT + ⏻	Shift + Power		
TV/VIDEO SLEEP	Tv/ Video	SEARCH TV/R	TV/ R		
TV VOL MASTER VOL +	Tv Vol +	SHIFT + + VOL	Shift + Vol +		
–	Tv Vol -	SHIFT + VOL –	Shift + Vol -		
TV CH – PRESET –	Tv CH-	SHIFT + CH –	Shift + Ch -		
TV CH + PRESET +	Tv CH+	SHIFT + + CH	Shift + Ch +		

Original		Replacement	
STANDBY	Power		Power
AV I/⏻ SYSTEM	Power AV	SHIFT +	Shift + Power
AUTO CAL	Auto Cal	HOME SMART	Smart
TV/VIDEO SLEEP	Sleep	PROG SLEEP	Sleep
A.F.D.	A. F. D.	B	Green
MOVIE	Movie	C	Yellow
MUSIC	Music	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0

Original		Replacement	
>10/* -/-- CLEAR	-/--/>10	-/-- GUIDE	Guide
MEMORY ENTER	Enter/Memory	FAV PRE-CH	Pre Ch
FM MODE	FM Mode	SEARCH TV/R	TV/R
DUAL MONO	Dual Mono	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
MUTING	Muting	MUTE	Mute
TV VOL MASTER VOL +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
MENU	Menu	TOP MENU MENU	Menu
	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original	Replacement
TUNING – <<< Tuning-	<<
TUNING + >>> Tuning+	>>
TV CH + PRESET + >>I / Preset +	>>I
TV CH – PRESET – I<<< / Preset -	I <<
REPLAY ← / Replay	CH – Ch -
ADVANCE → / Advance	+ CH Ch +
VIDEO 2 Video 2	APP MEDIA Media
SA-CD/CD SA-CD/CD	SHIFT + APP MEDIA Shift + Media
AV SYSTEM Power AV	TIMER AV AV
2CH 2CH	A Red
D.TUNING D.SKIP D.Tuning/D.Skip SA-CD/CD	PICTURE FORMAT Format
MEMORY ENTER Enter/Memory SA-CD/CD	SHIFT + FAV PRE-CH Shift + Pre Ch
1 1 SA-CD/CD	SHIFT + 1 Shift + 1
2 2 SA-CD/CD	SHIFT + 2 Shift + 2
3 3 SA-CD/CD	SHIFT + 3 Shift + 3
4 4 SA-CD/CD	SHIFT + 4 Shift + 4
5 5 SA-CD/CD	SHIFT + 5 Shift + 5

Original	Replacement
6 6 SA-CD/CD	SHIFT + 6 Shift + 6
7 7 SA-CD/CD	SHIFT + 7 Shift + 7
8 8 SA-CD/CD	SHIFT + 8 Shift + 8
9 9 SA-CD/CD	SHIFT + 9 Shift + 9
0/10 0/10 SA-CD/CD	SHIFT + 0 Shift + 0
>10/• -/-- CLEAR -/--/>10 SA-CD/CD	SHIFT + -/-- GUIDE Shift + Guide
DISPLAY Display SA-CD/CD	SHIFT + DISPLAY INFO Shift + Info
■ Stop SA-CD/CD	SHIFT + ■ Shift + Stop
II Pause	SHIFT + II Shift + Pause
▷ Play SA-CD/CD	SHIFT + PLAY MODE ▶ Shift + Play
TUNING – <<< Tuning-	SHIFT + << Shift + <<
TUNING + >>> Tuning+	SHIFT + >> Shift + >>
TV CH – PRESET – I<<< / Preset - SA-CD/CD	SHIFT + << Shift + I <<
TV CH + PRESET + >>I / Preset + SA-CD/CD	SHIFT + >>I Shift + >>I