Mandis shop

Sony RM-DC345

Original		Replacement		Original	Replacement
CONTINUE	Continue Play	HOME SMART	Smart		
SHUFFLE	Shuffle Play Mod	SOUND DUAL	Dual		
PROGRAM	Program Play	PROG SLEEP	Sleep		
REPEAT	Repeat	REPEAT TEXT	Text		
TIME	Time	TIMER AV	AV		
DISC SKIP	Disc Skip	DISPLAY INFO	Info		
▶	Play	PLAY MODE ▶	Play		
❚❚	Pause	❚❚	Pause		
■	Stop	■	Stop		
AMS ▶▶❚	AMS >>❚	≫❚	>>❚		
AMS ❚◀◀	❚<< AMS	❚≪	❚<<		
▶▶	>>	≫	>>		
◀◀	<<	≪	<<		
+ ANALOG OUT LEVEL	Analog Out	+ VOL	Vol +		
ANALOG OUT LEVEL −	Analog Out Level	VOL −	Vol -		

https://remotecontrols.com/Sony/1081563-replacement-remote-control-for-Sony-RM-DC345-148572.htm