Original	Replacement
Mute	Mute / Dimmer
Power Video	Shift + Power
Power	Power
[ ]	Picture / Format
[i+]	Info / Angle
→ ←	Smart / List
[⏲]	Sleep / Timer
Text	Text / Goto
◨ / ◳	Setup / OPT /
Input	AV / Input / RDS
[I]	Shift + Guide / EPG / -/--
◳ / ◨	D.Menu / Top
↑	Zoom / Size
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
CH+	Shift + CH+ / Page+

Original	Replacement
[>I<]	Display / Media
CH-	Shift + CH- /
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	Guide / EPG / -/--
0	0
Recall	Back / Return

Original		Replacement		Original	Replacement
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	Up		Up		
	Left		Left		
	OK		OK		
	Right		Right		
	Down		Down		
	Vol +		Vol +		
	Progr +		CH+ / Page+		
	Menu		Menu / Home		
	Vol -		Vol -		
	Progr -		CH- / Page-		

Original		Replacement		Original	Replacement
	Power Video		Power		
	→ ←		Smart / List		
	[O]		Sleep / Timer		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	CH+		CH+ / Page+		
	CH-		CH- / Page-		
	Stop		Stop / Hold		
	Pause		Pause / Step / Freeze		
	Rec		Rec / Rec Mode		

Original		Replacement		Original		Replacement	
	Power Video		Power				
	→ ←		Smart / List				
	[O]		Sleep / Timer				
	<<		<< / Tune-				
	Play		Play / Slow				
	>>		>> / Tune+				
	CH+		CH+ / Page+				
	CH-		CH- / Page-				
	Stop		Stop / Hold				
	Pause		Pause / Step / Freeze				
	Rec		Rec / Rec Mode				

Original	Replacement	Original	Replacement
Power Video	Power		
→ ←	Smart / List		
[O]	Sleep / Timer		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		