Mandis shop

RMT- 234

Original		Replacement		Original	Replacement
ON	Power		Power		
PROGRAM +	Program+	CH +	Ch +		
PROGR	Program-	CH −	Ch -		
	Rec	REC MODE	Rec		
PLAY	Play	PLAY MODE	Play		
FF	>>		>>		
REW	<<		<<		
STOP	Stop		Stop		
PAUSE	Pause		Pause		

https://remotecontrols.com/Sony/10632-879-replacement-remote-control-for-Sony-RMT-234-143852.htm