Mandis shop

# Sony RMT-708

| Original | | Replacement | |
|---|---|---|---|
| PLAY | Play | SLOW ▶ | Play / Slow |
| START/STOP | Start/Stop | ⏻ | Power |
| START/STOP | Start/Stop | REC MODE ● | Rec / Rec Mode |
| REW ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| FF ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| STOP | Stop | HOLD ■ | Stop / Hold |
| | T | + CH PAGE | CH+ / Page+ |
| PAUSE | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| SLOW | I>/Slow | | Right |
| SLOW | I>/Slow | SHIFT + SLOW ▶ | Shift + Play / |
| | W | CH PAGE − | CH- / Page- |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://remote-controls.ch/en/Sony/1068047-6337-replacement-remote-control-for-Sony-RMT-708-146757423.html