Mandis shop

# Teac RC-1195

| Original | Replacement |
|---|---|
| Standby / On | Power |
| Dimmer | Ok |
| Function | Options |
| Timer | AV |
| Sleep | Sleep |
| FM / AM | Smart |
| FM Mode / Shuffle | TV/R |
| PTY / Repeat | Text |
| RDS / MP3 | Media |
| I<< / Tuning - | I<< |
| >>I / Tuning + | >>I |
| Play / Pause | Play |
| Play / Pause | Pause |
| Preset/Folder | Ch - |
| Preset/Folder Up | Ch + |
| Stop | Stop |
| Bass | Left |

| Original | Replacement |
|---|---|
| Treble | Right |
| Volume (Bass/Treble) + | Vol + |
| Volume (Bass/Treble) - | Vol - |
| Memory / Time | Menu |
| Muting | Mute |

https://remote-controls.ch/en/Teac/1058323-46292-replacement-remote-control-for-Teac-RC-1195.html