Original	Replacement
Power Receiver	Power
Power Audio	Red / Netflix / Search
Power TV	Blue / Prime Video / Random
Power VCR	Shift + Red / Netflix /
Power VDP	Yellow / YouTube / Repeat
Power CD	Green / APP / Repeat
Power TAPE	Shift + Green / APP /
TUNER	Shift + 6
CD	Shift + 3
TAPE MONITOR	Shift + 5
TV/VCR 2	Shift + 1
VDP	Shift + 2
VCR1	Shift + 4
CH Level -	CH- / Page-
CH Level +	CH+ / Page+
Test	Text / Goto
CH Select	Setup / OPT / Tools

Original	Replacement
Surround	Eject / Surround
3 Stereo	Audio / Lang I/II
Help	Info / Angle
Disc	Smart / List
Disc Enter	Display / Media
TV / AV	AV / Input / RDS
TUNER 1	1
TUNER 2	2
TUNER 3	3
Direct Tuning	Menu / Home
TV Vol +	Shift + Vol +
TUNER 4	4
TUNER 5	5
TUNER 6	6
TUNER >=10	Guide / EPG / -/--
TV Vol -	Shift + Vol -
TUNER 7	7

Original		Replacement		Original	Replacement
8	TUNER 8	USB 8	8		
9	TUNER 9	BLUETOOTH 9	9		
0	TUNER 0	HDMI - SAT 0	0		
◀◀	TAPE MON <<	TUNE- ◀◀	<< / Tune-		
▶▶	TAPE MON >>	TUNE+ ▶▶	>> / Tune+		
DECK1/2	TAPE MON Deck	OK	OK		
◀	TAPE MON Rev.	◀	Left		
❚❚	TAPE MON	STEP - FREEZE ❚❚	Pause / Step / Freeze		
■	TAPE MON Stop	HOLD ■	Stop / Hold		
▶	TAPE MON Play	SLOW ▶	Play / Slow		
▶	TAPE MON Play	▶	Right		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLU −	Volume-	VOL −	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original	Replacement
Power Receiver	Power
Power Audio	Red / Netflix / Search
Power TV	Blue / Prime Video / Random
Power VCR	Shift + Red / Netflix /
Power VDP	Yellow / YouTube / Repeat
Power CD	Green / APP / Repeat
Power TAPE	Shift + Green / APP /
TUNER	Shift + 6
CD	Shift + 3
TAPE MONITOR	Shift + 5
TV/VCR 2	Shift + 1
VDP	Shift + 2
VCR1	Shift + 4
CH Level -	CH- / Page-
CH Level +	CH+ / Page+
Test	Text / Goto
CH Select	Setup / OPT / Tools

Original	Replacement
Surround	Eject / Surround
3 Stereo	Audio / Lang I/II
Help	Info / Angle
Disc	Smart / List
Disc Enter	Display / Media
TV / AV	AV / Input / RDS
CD 1	1
CD 2	2
CD 3	3
Direct Tuning	Menu / Home
TV Vol +	Shift + Vol +
CD 4	4
CD 5	5
CD 6	6
CD >=10	Guide / EPG / -/--
TV Vol -	Shift + Vol -
CD 7	7

Original		Replacement		Original	Replacement
8	CD 8	8	8		
9	CD 9	9	9		
0	CD 0	0	0		
⏮	CD I <<	PRESET- ⏮	I << / Preset-		
⏭	CD >>I	PRESET+ ⏭	>>I / Preset+		
◀◀	CD <<	TUNE- ◀◀	<< / Tune-		
▶▶	CD >>	TUNE+ ▶▶	>> / Tune+		
❚❚	CD Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	CD Stop	HOLD ■	Stop / Hold		
▶	CD Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME −	Volume-	VOL −	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original	Replacement
Power Receiver	Power
Power Audio	Red / Netflix / Search
Power TV	Blue / Prime Video / Random
Power VCR	Shift + Red / Netflix /
Power VDP	Yellow / YouTube / Repeat
Power CD	Green / APP / Repeat
Power TAPE	Shift + Green / APP /
TUNER	Shift + 6
CD	Shift + 3
TAPE MONITOR	Shift + 5
TV/VCR 2	Shift + 1
VDP	Shift + 2
VCR1	Shift + 4
CH Level -	CH- / Page-
CH Level +	CH+ / Page+
Test	Text / Goto
CH Select	Setup / OPT / Tools

Original	Replacement
Surround	Eject / Surround
3 Stereo	Audio / Lang I/II
Help	Info / Angle
Disc	Smart / List
Disc Enter	Display / Media
TV / AV	AV / Input / RDS
VDP 1	1
VDP 2	2
VDP 3	3
Direct Tuning	Menu / Home
TV Vol +	Shift + Vol +
VDP 4	4
VDP 5	5
VDP 6	6
VDP >=10	Guide / EPG / -/--
TV Vol -	Shift + Vol -
VDP 7	7

Original		Replacement		Original	Replacement
8	VDP 8	8	8		
9	VDP 9	9	9		
0	VDP 0	0	0		
⏮	VDP I <<	PRESET- ⏮	I << / Preset-		
⏭	VDP >>I	PRESET+ ⏭	>>I / Preset+		
◀◀	VDP <<	TUNE- ◀◀	<< / Tune-		
▶▶	VDP >>	TUNE+ ▶▶	>> / Tune+		
❚❚	VDP Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	VDP Stop	HOLD ■	Stop / Hold		
▶	VDP Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME −	Volume-	VOL −	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original	Replacement	Original	Replacement
RECEIVER Power Receiver	Power	SURROUND Surround	SURROUND Eject / Surround
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	HELP Help	ANGLE INFO Info / Angle
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	DISC Disc	LIST SMART Smart / List
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
CD Power CD	APP REPEAT Green / APP / Repeat	TV AV TV / AV	RDS AV INPUT AV / Input / RDS
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	1 VCR 1 1	TV 1 1
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	2 VCR 1 2	DVD 2 2
CD CD	SHIFT + CD-STB 3 Shift + 3	3 VCR 1 3	CD-STB 3 3
TAPE MONITOR TAPE MONITOR	SHIFT + TAPE 5 Shift + 5	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
TV/VCR2 TV/VCR 2	SHIFT + TV 1 Shift + 1	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VDP VDP	SHIFT + DVD 2 Shift + 2	4 VCR 1 4	VIDEO 4 4
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	5 VCR 1 5	TAPE 5 5
CH LEVEL - CH Level -	CH PAGE − CH- / Page-	6 VCR 1 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- VCR 1 >=10	-/-- GUIDE EPG Guide / EPG / -/--
TEST Test	GOTO TEXT Text / Goto	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -
CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT / Tools	7 VCR 1 7	AUX-HDD 7 7

Original		Replacement		Original	Replacement
8	VCR 1 8	USB 8	8		
9	VCR 1 9	BLUETOOTH 9	9		
0	VCR 1 0	HDMI - SAT 0	0		
◀◀	VCR 1 <<	TUNE- ◀◀	<< / Tune-		
▶▶	VCR 1 >>	TUNE+ ▶▶	>> / Tune+		
❚❚	VCR 1 Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	VCR 1 Stop	HOLD ■	Stop / Hold		
▶	VCR 1 Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME –	Volume-	VOL –	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		