Mandis shop

10201

Original		Replacement		Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
	Zoom+	SIZE ZOOM	Zoom / Size				
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /				
	Sleep	TIMER SLEEP	Sleep / Timer				
ROTATE	Rotate	RETURN BACK	Back / Return				
COPY/DEL	Copy/Del	LIST SMART	Smart / List				
	Up		Up				
	Left		Left				
ENTER	Enter	OK	OK				
	Right		Right				
SLIDE SHOW	Slide Show	PROGRAM TV/RADIO	TV/Radio /				
STOP	Stop	HOLD	Stop / Hold				
	Down		Down				

https://remotecontrols.com/Telefunken/1033930-replacement-remote-control-for-Telefunken-10201.htm