Original		Replacement	
	Power		Power
	Premium On	HOME SMART	Smart
	Guida	GUIDE	Guide
	Menu	TOP MENU MENU	Menu
	Info	DISPLAY INFO	Info
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	P+	CH +	Ch +
	P-	CH −	Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
Back	Back	RETURN BACK	Back
STOP Exit	Exit	CLEAR EXIT	Exit
STOP Exit	Stop		Stop

Original		Replacement	
PAUSE/PLAY	Play	PLAY MODE	Play
PAUSE/PLAY	Pause		Pause
FWD	>>		>>
REW	<<		<<
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Lista	Lista	DISC NAV LIST	List
Opzioni	Opzioni	SETTINGS OPT	Options
	Red	A	Red

Original		Replacement		Original	Replacement
TEXT	Green	B	Green		
APP	Yellow	C	Yellow		
	Blue	D	Blue		
TEXT	Text	REPEAT TEXT	Text		
APP	APP	APP MEDIA	Media		
	Recall	FAV PRE-CH	Pre Ch		