| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| AD | AD | TITLE SOUND | Sound / Title |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Source | RDS AV INPUT | AV / Input / RDS |
| + | Vol + | + VOL | Vol + |
| CONTENT MENU ATV DTV | ATV/DTV/Content Menu | LIST SMART | Smart / List |
| P | P+ | + CH PAGE | CH+ / Page+ |
| | Vol - | VOL − | Vol - |

| Original | | Replacement | |
|---|---|---|---|
| | Mute | DIMMER MUTE | Mute / Dimmer |
| P | P- | CH PAGE − | CH- / Page- |
| TOP MENU GUIDE | Guide/Top | TOP MENU D.MENU | D.Menu / Top |
| TOP MENU GUIDE | Guide/Top | -/-- GUIDE EPG | Guide / EPG / -/-- |
| RETURN EXIT | Exit/Return | RETURN BACK | Back / Return |
| RETURN EXIT | Exit/Return | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| DVD MENU MENU | Menu/DVD | HOME MENU | Menu / Home |
| | Down | | Down |
| SET UP TV/FAV RADIO | Tv/FAV/Radio/Set | PROGRAM TV/ RADIO | TV/Radio / |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | [ <>] | FORMAT PICTURE | Picture / Format | | |
| | ←[ / ]→ | MEDIA DISPLAY | Display / Media | | |
| | [ i+] / [ ≡i ] | ANGLE INFO | Info / Angle | | |
| AUDIO TEXT | Text | GOTO TEXT | Text / Goto | | |
| AUDIO TEXT | Audio | LANG I/II AUDIO | Audio / Lang I/II | | |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ | | |
| SUBTITLE | Eject | SURROUND | Eject / Surround | | |
| CD I/II | O) I / I I | SHIFT + LANG I/II AUDIO | Shift + Audio / Lang I/II | | |
| CD I/II | Stop | HOLD | Stop / Hold | | |
| | Play/ [ ≡o] | SLOW | Play / Slow | | |
| | I I / I I >/ [ ▼] | STEP-FREEZE | Pause / Step / Freeze | | |
| | I <</ [ ≡?] | PRESET- | I << / Preset- | | |
| | <</ [ ≡+] | TUNE- | << / Tune- | | |
| | >>/ [ ≡♦] | TUNE+ | >> / Tune+ | | |
| | >>I / [ O] / [ ≡X] | PRESET+ | >>I / Preset+ | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Exit / Return | Exit / Cancel / Clear |
| 1 | 1 | Exit / Return | Back / Return |
| 2 | 2 | Up | Up |
| 3 | 3 | Left | Left |
| 4 | 4 | OK | OK |
| 5 | 5 | Right | Right |
| 6 | 6 | Menu/ DVD | Menu / Home |
| 7 | 7 | Down | Down |
| 8 | 8 | Tv/ FAV/ Radio/ Set | TV/ Radio / |
| 9 | 9 | Tv/ FAV/ Radio/ Set | Setup / OPT / |
| 0 | 0 | [<>] | Picture / Format |
| Source | AV / Input / RDS | ←[/]→ | Display / Media |
| Vol + | Vol + | [i+]/[≡i] | Info / Angle |
| Vol - | Vol - | Text | Text / Goto |
| Mute | Mute / Dimmer | Audio | Audio / Lang I/II |
| Guide/ Top | Guide / EPG / -/-- | Subtitle | Subtitle / EQ |
| Guide/ Top | D. Menu / Top | Eject | Eject / Surround |
| Menu | Menu | | |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | O) I / I I | SHIFT + LANG I/II AUDIO | Shift + Audio / Lang I/II | | |
| | Stop | HOLD | Stop / Hold | | |
| | Play/ [ ≡o] | SLOW | Play / Slow | | |
| | I I / I I >/ [ ▼] | STEP-FREEZE | Pause / Step / Freeze | | |
| | I <</ [ ≡?] | PRESET- | I << / Preset- | | |
| | <</ [ ≡+] | TUNE- | << / Tune- | | |
| | >>/ [ ≡♦] | TUNE+ | >> / Tune+ | | |
| | >>I / [ O] / [ ≡X] | PRESET+ | >>I / Preset+ | | |

| Original | | Replacement | |
|---|---|---|---|
| Power | | Power | |
| 1 | | 1 | |
| 2 | | 2 | |
| 3 | | 3 | |
| 4 | | 4 | |
| 5 | | 5 | |
| 6 | | 6 | |
| 7 | | 7 | |
| 8 | | 8 | |
| 9 | | 9 | |
| AD | | Sound / Title | |
| 0 | | 0 | |
| Source | | AV / Input / RDS | |
| Vol + | | Vol + | |
| ATV/ DTV/ Content Menu | | Setup / OPT / | |
| P+ | | CH+ / Page+ | |
| Vol - | | Vol - | |

| Original | | Replacement | |
|---|---|---|---|
| Mute | | Mute / Dimmer | |
| P- | | CH- / Page- | |
| Guide/Top | | Guide / EPG / -/-- | |
| Guide/Top | | D.Menu / Top | |
| Exit/Return | | Exit / Cancel / Clear | |
| Exit/Return | | Back / Return | |
| Up | | Up | |
| Left | | Left | |
| OK | | OK | |
| Right | | Right | |
| Menu/DVD | | Menu / Home | |
| Down | | Down | |
| Tv/FAV/Radio/Set | | TV/Radio / | |
| Red | | Red / Netflix / Search | |
| Green | | Green / APP / Repeat | |
| Yellow | | Yellow / YouTube / Repeat | |
| Blue | | Blue / Prime Video / Random | |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | [<>] | FORMAT PICTURE | Picture / Format | | |
| | ←[/]→ | MEDIA DISPLAY | Display / Media | | |
| | [i+]/[≡i] | ANGLE INFO | Info / Angle | | |
| AUDIO TEXT | Text | GOTO TEXT | Text / Goto | | |
| AUDIO TEXT | Audio | LANG I/II AUDIO | Audio / Lang I/II | | |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ | | |
| SUBTITLE | Eject | SURROUND | Eject / Surround | | |
| CD I/II | O)I/II | SHIFT + LANG I/II AUDIO | Shift + Audio / Lang I/II | | |
| CD I/II | Stop | HOLD | Stop / Hold | | |
| | Play/[≡o] | SLOW | Play / Slow | | |
| | II/II>/[▼] | STEP-FREEZE | Pause / Step / Freeze | | |
| | I<</[≡?] | PRESET- | I<< / Preset- | | |
| | <</[≡+] | TUNE- | << / Tune- | | |
| | >>/[≡♦] | TUNE+ | >> / Tune+ | | |
| | >>I/[O]/[≡X] | PRESET+ | >>I / Preset+ | | |
| | | | | | |
| | | | | | |