# Mandis shop

RC4875

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Source | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| | TV | PROGRAM TV/ RADIO | TV/ Radio / |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Recall | PC FAV MARKER | Fav / Marker / PC |
| +V | V+ | + VOL | Vol + |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| +P | P+ | + CH PAGE | CH+ / Page+ |

| Original | | Replacement | |
|---|---|---|---|
| -V | V- | VOL - | Vol - |
| | World/Internet | LIST SMART | Smart / List |
| -P | P- | CH PAGE - | CH- / Page- |
| MENU | Menu | HOME MENU | Menu / Home |
| Q.MENU | Q. Menu | TOP MENU D.MENU | D. Menu / Top |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| BACK | Back | RETURN BACK | Back / Return |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| i | i | ANGLE INFO | Info / Angle |
| | Music/Camera | MEDIA DISPLAY | Display / Media |
| | TV Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| */O | */O | SHIFT + TV 1 | Shift + 1 |
| */Q | */Q | SHIFT + DVD 2 | Shift + 2 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| [ ≡] / Text | GOTO TEXT — Text / Goto | | |
| Red | NETFLIX SEARCH — Red / Netflix / Search | | |
| Green | APP REPEAT — Green / APP / Repeat | | |
| Yellow | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| Blue | Prime Video RANDOM — Blue / Prime Video / Random | | |
| Lang | LANG I/II AUDIO — Audio / Lang I/II | | |
| [ ≡] . . | TITLE SOUND — Sound / Title | | |
| [ - O- ] | OPT-TOOLS SETUP — Setup / OPT / | | |
| << | TUNE- << — << / Tune- | | |
| Pause | STEP-FREEZE II — Pause / Step / Freeze | | |
| >> | TUNE+ >> — >> / Tune+ | | |
| Rec | REC MODE — Rec / Rec Mode | | |
| Play | SLOW — Play / Slow | | |
| Stop | HOLD — Stop / Hold | | |
| | | | |
| | | | |
| | | | |