Original		Replacement	
STANDBY	Standby	SHIFT + Power	Shift + Power
POWER	Power	Power	Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PHONO	Phono	PC FAV MARKER	Fav / Marker / PC
TUNER	Tuner	TUNER 6	6
CD	CD	CD-STB 3	3
MULTI CH IN	Multi CH In	-/-- GUIDE EPG	Guide / EPG / -/--
V-AUX/DOCK	V-AUX	AUX-HDD 7	7
CBL/SAT	CBL/SAT	HDMI-SAT 0	0
MD/TAPE	MD/TAPE	TAPE 5	5
CD-R	CD-R	USB 8	8
DTV	DTV	TV 1	1
VCR 1	VCR 1	VIDEO 4	4
DVR/VCR 2	DVR / VCR 2	BLUETOOTH 9	9
DVD	DVD	DVD 2	2
VOLUME +	Volume+	+ VOL	Vol +
VOLUME –	Volume-	VOL –	Vol -

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET/CH ▲	Up / Preset/CH+	▲	Up
SET MENU MENU SRCH MODE	Menu	HOME MENU	Menu / Home
PURE DIRECT	Pure Direct	OPT-TOOLS SETUP	Setup / OPT /
◀	Left / A/B/C/D/E	◀	Left
ENTER	Enter	OK	OK
▶ A/B/C/D/E	Right /	▶	Right
RETURN MEMORY	Return	RETURN BACK	Back / Return
▼	Down / Preset/CH-	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
STRAIGHT EFFECT	Straight Effec	PROGRAM TV/RADIO	TV/Radio /
CLASSICAL	Classical	TITLE SOUND	Sound / Title
LIVE/CLUB	Live Club	LANG I/II AUDIO	Audio / Lang I/II
ENTERTAIN	Entertain	SIZE ZOOM	Zoom / Size
MOVIE	Movie	FORMAT PICTURE	Picture / Format
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
SUR. DECODE	Sur Decode	RDS AV INPUT	AV / Input / RDS

Original		Replacement		Original		Replacement	
SELECT	Select	GOTO TEXT	Text / Goto				
EXTD SUR.	Extd Sur.	SURROUND	Eject / Surround				
NIGHT	Night	LIST SMART	Smart / List				
FREQ/TEXT	Freq/RDS	SLOW	Play / Slow				
EON	EON	STEP-FREEZE	Pause / Step / Freeze				
MODE – PTY SEE	PTY Seek Mode	TUNE-	<< / Tune-				
Y SEEK – START	PTY Seek Start	TUNE+	>> / Tune+				

Original		Replacement	
POWER	Power		Power
VOLUME +	Vol +	VOL +	Vol +
VOLUME –	Vol -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET/CH ▲	Preset Up	▲	Up
PRESET/CH ▲	Preset Up	PRESET+ ⏭	>>I / Preset +
◀	Left A/B/C/D/E	◀	Left
ENTER	Enter	OK	OK
▶ A/B/C/D/E	Right A/B/C/D/	▶	Right
▼	Preset Down	PRESET- ⏮	I<< / Preset -
▼	Preset Down	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLASSICAL	1	TV 1	1
LIVE/CLUB	2	DVD 2	2
ENTERTAIN	3	CD - STB 3	3
MOVIE	4	VIDEO 4	4
STEREO	5	TAPE 5	5

Original		Replacement	
SUR. DECODE 6	6	TUNER 6	6
SELECT 7	7	AUX - HDD 7	7
EXTD SUR. 8	8	USB 8	8
1 MEMORY 9	9	BLUETOOTH 9	9
MEMORY 2 0	0	HDMI - SAT 0	0
ENHANCER	ENT	PC FAV MARKER	Fav / Marker / PC
FREQ/TEXT NET RADIO	Freq/RDS	SLOW ▶	Play / Slow
EON USB	Eon	STEP - FREEZE ⏸	Pause / Step / Freeze
MODE – PTY SEEK	Mode PTY Seek	TUNE- ⏪	<< / Tune-
PTY SEEK – START	PTY Seek Start	TUNE+ ⏩	>> / Tune+