Original		Rechange	
	POWER		Power
	↩○	SHIFT + LIST SMART	Shift + Smart / List
	☼*/Ö	SHIFT + MEDIA DISPLAY	Shift + Display / Media
	☼²/♀	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	SOURCE	RDS AV INPUT	AV / Input / RDS
	PRESETS	LIST SMART	Smart / List
	┼┼┼	OPT-TOOLS SETUP	Setup / OPT /
	♫/☺◘	MEDIA DISPLAY	Display / Media
	SLEEP	TIMER SLEEP	Sleep / Timer
1	1 . /@	TV 1	1
2 abc	2 abc	DVD 2	2
3 def	3 def	CD - STB 3	3
4 ghi	4 ghi	VIDEO 4	4
5 jkl	5 jkl	TAPE 5	5
6 mno	6 mno	TUNER 6	6
7 pqrs	7 pqrs	AUX - HDD 7	7
8 tuv	8 tuv	USB 8	8

Original		Rechange	
9 wxyz	9 wxyz	BLUETOOTH 9	9
	TV	PROGRAM TV/ RADIO	TV/Radio /
0	0	HDMI - SAT 0	0
	↔	SHIFT + RETURN BACK	Shift + Back / Return
	TV GUIDE	-/-- GUIDE EPG	Guide / EPG / -/--
	[≡]	GOTO TEXT	Text / Goto
MENU	MENU	HOME MENU	Menu / Home
Q.MENU	Q.MENU	TOP MENU D.MENU	D.Menu / Top
	UP		Up
	LEFT		Left
OK	OK	OK	OK
	RIGHT		Right
	DOWN		Down
BACK	BACK	RETURN BACK	Back / Return
	⇥	FORMAT PICTURE	Picture / Format
EXIT	EXIT	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	☼FAV	PC FAV MARKER	Fav / Marker / PC

Original	Rechange	Original	Rechange
VOL+	Vol +	BLUE	Blue / Prime Video / Random
MUTE	Mute / Dimmer		
P+	CH+ / Page+		
VOL-	Vol -		
INFO	Info / Angle		
P-	CH- / Page-		
REC	Rec / Rec Mode		
PLAY	Play / Slow		
PAUSE	Pause / Step / Freeze		
STOP	Stop / Hold		
LANG.	Audio / Lang I/II		
<<	<< / Tune-		
>>	>> / Tune+		
[≡]...	Sound / Title		
RED	Red / Netflix / Search		
GREEN	Green / APP / Repeat		
YELLOW	Yellow / YouTube / Repeat		