Original		Rechange	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PR.LIST	PR. List	LIST SMART	Smart / List
0	0	HDMI-SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return
VOL +	Vol +	VOL +	Vol +
PIC.MODE	Pic. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title

Original		Rechange	
CH +	CH+	CH PAGE +	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
CH −	CH-	CH PAGE −	CH- / Page-
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
MENU	Menu	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Rec	REC MODE	Rec / Rec Mode
	Rec List	SHIFT + REC MODE	Shift + Rec / Rec Mode
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
Yellow	YouTube / REPEAT A-B — Yellow / YouTube / Repeat	>>	TUNE+ — >> / Tune+
Blue	Prime Video / RANDOM — Blue / Prime Video / Random		
PC Auto	SURROUND — Eject / Surround		
Tv/Radio	PROGRAM / TV/RADIO — TV/Radio /		
I/II/Audio	LANG I/II / AUDIO — Audio / Lang I/II		
Subtitle	EQ / SUBTITLE — Subtitle / EQ		
Index	MEDIA / DISPLAY — Display / Media		
Reveal	SHIFT + RETURN / BACK — Shift + Back / Return		
Freeze	SHIFT + STEP-FREEZE — Shift + Pause / Step /		
Info	ANGLE / INFO — Info / Angle		
Text	GOTO / TEXT — Text / Goto		
Play/Size	SLOW — Play / Slow		
Pause/Subpage	STEP-FREEZE — Pause / Step / Freeze		
Stop/Hold	HOLD — Stop / Hold		
I<<	PRESET- — I<< / Preset-		
>>I	PRESET+ — >>I / Preset+		
<<	TUNE- — << / Tune-		