Mandis shop

Panasonic N2QAYB000272

Original		Rechange	
BD	Power BD		Power
	Power Tv	SHIFT +	Shift + Power
CH	CH+ Tv	SHIFT + CH PAGE	Shift + CH+ /
VOL	Vol + Tv	VOL	Vol +
DRIVE SELECT	Drive Select	TOP MENU D.MENU	D. Menu / Top
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH	CH- Tv	SHIFT + CH PAGE	Shift + CH- /
VOL	Vol - Tv	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
PAGE CH	CH+	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH-	CH PAGE	CH- / Page-
7	7	AUX - HDD 7	7

Original		Rechange	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PROG/CHECK	Prog/ Check	PROGRAM TV/ RADIO	TV/ Radio /
DELETE *	Delete/ *	SIZE ZOOM	Zoom / Size
0	0	HDMI - SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
MANUAL SKIP	Manual Skip	FORMAT PICTURE	Picture / Format
⏮	I << Skip	PRESET- ⏮	I << / Preset-
⏭	Skip >>I	PRESET+ ⏭	>>I / Preset+
◀◀	<< Slow/ Search	TUNE- ◀◀	<< / Tune-
▶▶	Slow/ Search >>	TUNE+ ▶▶	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play/ x1. 3	SLOW	Play / Slow
STATUS	i / Status	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Rechange	Original	Rechange
Direct Navigator / Pop-up	Smart / List	Text	Text / Goto
Left / ◁ I	Left	[≡◆] / Sttl	Subtitle / EQ
OK	OK	Display	Display / Media
Up	Up	Time Slip	Sleep / Timer
Right / I I >	Right		
Function / Menu	Menu / Home		
Option	Setup / OPT /		
Down	Down		
Return	Back / Return		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow / Create Chapter	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Rec	Rec / Rec Mode		
Rec Mode	Shift + Rec / Rec Mode		
Audio	Audio / Lang I / II		
Direct Tv Rec	Eject / Surround		