Original		Rechange	
	Power TV		Power
	Mute TV TV	DIMMER MUTE	Mute / Dimmer
	Play/Save TV	SLOW	Play / Slow
	Pause TV	STEP-FREEZE	Pause / Step / Freeze
	Stop TV	HOLD	Stop / Hold
	Rec TV	REC MODE	Rec / Rec Mode
	<<Tuner- TV	TUNE-	<< / Tune-
	>>Tuner+ TV	TUNE+	>> / Tune+
	PR-/I<< TV	PRESET-	I<< / Preset-
	PR+/>>I TV	PRESET+	>>I / Preset+
	Level TV	TITLE SOUND	Sound / Title
	Subwoofer TV	LANG I/II AUDIO	Audio / Lang I/II
	Equalizer TV	EQ SUBTITLE	Subtitle / EQ
	Surround TV	SURROUND	Eject / Surround
	Night TV	TIMER SLEEP	Sleep / Timer
	Setup TV	OPT-TOOLS SETUP	Setup / OPT /
	Menu TV TV	HOME MENU	Menu / Home

Original		Rechange	
	Up TV		Up
	Left/RDS TV		Left
	OK TV	OK	OK
	Right/PTY TV		Right
	Clear TV	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down TV		Down
	Back/ST-Mono	RETURN BACK	Back / Return
	Vol+ TV TV	+ VOL	Vol+
	PR+/>>I TV	+ CH PAGE	CH+ / Page+
	Vol- TV TV	VOL −	Vol-
	PR-/I<< TV	CH PAGE −	CH- / Page-
	1 Tv	TV 1	1
	2 TV	DVD 2	2
	3 TV	CD-STB 3	3
	4 TV	VIDEO 4	4
	5 TV	TAPE 5	5
	6 TV	TUNER 6	6

Original		Rechange	
	7 TV	AUX-HDD 7	7
	8 TV	USB 8	8
	9 TV	BLUETOOTH 9	9
GUIDE	Guide TV	-/-- GUIDE EPG	Guide / EPG / -/--
	0 TV	HDMI-SAT 0	0
TAPE-CD	Tape-CD	NETFLIX SEARCH	Red / Netflix / Search
AUX 1 (VCR)	AUX1 (VCR)	APP REPEAT	Green / APP / Repeat
AUX 2 (SAT-CABLE)	Aux2 (SAT-Cable	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Power AUX1	SHIFT +	Shift + Power
SAVE	Play/Save AUX1	SHIFT + SLOW	Shift + Play /
	Pause AUX1	SHIFT + STEP-FREEZE	Shift + Pause / Step /
	Stop AUX1	SHIFT + HOLD	Shift + Stop /
	Rec AUX1	SHIFT + REC MODE	Shift + Rec / Rec Mode
TUNER -	<</ Tuner -	SHIFT + TUNE-	Shift + << /
TUNER +	>>/ Tuner +	SHIFT + TUNE+	Shift + >> /
	PR-/ I <<AUX1	SHIFT + PRESET-	Shift + I << / Preset-
	PR+/ >>I AUX1	SHIFT + PRESET+	Shift + >>I / Preset+

Original		Rechange	
	Up AUX1	SHIFT +	Shift + Up
	Left/RDS AUX1	SHIFT +	Shift + Left
OK	OK AUX1	SHIFT + OK	Shift + OK
	Right/PTY AUX1	SHIFT +	Shift + Right
	Down AUX1	SHIFT +	Shift + Down
	PR+/ >>I AUX1	SHIFT + CH PAGE +	Shift + CH+ /
	PR-/ I <<AUX1	SHIFT + CH PAGE −	Shift + CH- /
	1 AUX1	SHIFT + TV 1	Shift + 1
	2 AUX1	SHIFT + DVD 2	Shift + 2
	3 AUX1	SHIFT + CD-STB 3	Shift + 3
	4 AUX1	SHIFT + VIDEO 4	Shift + 4
	5 AUX1	SHIFT + TAPE 5	Shift + 5
	6 AUX1	SHIFT + TUNER 6	Shift + 6
	7 AUX1	SHIFT + AUX-HDD 7	Shift + 7
	8 AUX1	SHIFT + USB 8	Shift + 8
	9 AUX1	SHIFT + BLUETOOTH 9	Shift + 9
GUIDE	Guide AUX1	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--

Original	Rechange	Original	Rechange
0 AUX1	SHIFT + HDMI - SAT 0	Shift + 0	

Original	Rechange	Original	Rechange
Power DVD6CH	Power	Up DVD6CH	Up
Mute DVD6CH	Mute / Dimmer	Left / RDS	Left
Play/Save	Play / Slow	OK DVD6CH	OK
Pause DVD6CH	Pause / Step / Freeze	Right / PTY	Right
Stop DVD6CH	Stop / Hold	Clear DVD6CH	Exit / Cancel / Clear
Rec DVD6CH	Rec / Rec Mode	Down DVD6CH	Down
<</ Tuner-	<< / Tune-	Back/ St-Mono	Back / Return
>>/ Tuner+	>> / Tune+	Vol + DVD6CH	Vol +
PR- / I <<	I << / Preset-	PR+/ >>I	CH+ / Page+
PR+/ >>I	>>I / Preset+	Vol - DVD6CH	Vol -
Level DVD6CH	Sound / Title	PR- / I <<	CH- / Page-
Subwoofer	Audio / Lang I/II	1 DVD6CH	1
Equalizer	Subtitle / EQ	2 DVD6CH	2
Surround	Eject / Surround	3 DVD6CH	3
Night DVD6CH	Sleep / Timer	4 DVD6CH	4
Setup DVD6CH	Setup / OPT /	5 DVD6CH	5
Menu DVD6CH	Menu / Home	6 DVD6CH	6

Original	Rechange
7 DVD6CH	7
8 DVD6CH	8
9 DVD6CH	9
Guide DVD6CH	Guide / EPG / -/--
0 DVD6CH	0
Tape- CD	Red / Netflix / Search
AUX1 (VCR)	Green / APP / Repeat
Aux2 (SAT- Cable	Yellow / YouTube / Repeat
Power Tape- CD	SHIFT + Power
Play/ Save	SHIFT + Shift + Play /
Pause Tape- CD	SHIFT + Shift + Pause / Step /
Stop Tape- CD	SHIFT + Shift + Stop /
Rec Tape- CD	SHIFT + Shift + Rec / Rec Mode
<</ Tuner -	SHIFT + Shift + << /
>>/ Tuner +	SHIFT + Shift + >> /
PR- / I <<	SHIFT + Shift + I << / Preset-
PR+/ >>I	SHIFT + Shift + >>I / Preset+

Original	Rechange
Up Tape- CD	SHIFT + Shift + Up
Left/ RDS Tape- CD	SHIFT + Shift + Left
OK Tape- CD	SHIFT + Shift + OK
Right/ PTY	SHIFT + Shift + Right
Down Tape- CD	SHIFT + Shift + Down
Back/ ST- Mono Tape- CD	SHIFT + Shift + Back / Return
PR+/ >>I	SHIFT + Shift + CH+ /
PR- / I <<	SHIFT + Shift + CH- /
1 Tape- CD	SHIFT + Shift + 1
2 Tape- CD	SHIFT + Shift + 2
3 Tape- CD	SHIFT + Shift + 3
4 Tape- CD	SHIFT + Shift + 4
5 Tape- CD	SHIFT + Shift + 5
6 Tape- CD	SHIFT + Shift + 6
7 Tape- CD	SHIFT + Shift + 7
8 Tape- CD	SHIFT + Shift + 8
9 Tape- CD	SHIFT + Shift + 9

Original	Rechange	Original	Rechange
0 Tape- CD	SHIFT + HDMI - SAT 0	Shi f t + 0	

Original	Rechange
Power TUNER	Power
Mute TUNER	Mute / Dimmer
Play/Save	Play / Slow
Pause TUNER	Pause / Step / Freeze
Stop TUNER	Stop / Hold
<<<Tuner-	<< / Tune-
>>>Tuner+	>> / Tune+
PR-/I << TUNER	I << / Preset-
PR+/ >>I TUNER	>>I / Preset+
Level TUNER	Sound / Title
Subwoofer	Audio / Lang I/II
Equalizer	Subtitle / EQ
Surround	Eject / Surround
Night TUNER	Sleep / Timer
Setup TUNER	Setup / OPT /
Menu TUNER	Menu / Home
Up TUNER	Up

Original	Rechange
Left/RDS TUNER	Left
OK TUNER	OK
Right/PTY	Right
Clear TUNER	Exit / Cancel / Clear
Down TUNER	Down
Back/St-Mono	Back / Return
Vol + TUNER	Vol +
PR+/ >>I TUNER	CH+ / Page+
Vol - TUNER	Vol -
PR-/I << TUNER	CH- / Page-
1 TUNER	1
2 TUNER	2
3 TUNER	3
4 TUNER	4
5 TUNER	5
6 TUNER	6
7 TUNER	7

Original	Rechange
8 TUNER	8
9 TUNER	9
Guide TUNER	Guide / EPG / -/--
0 TUNER	0
Tape- CD	Red / Netflix / Search
AUX1 (VCR)	Green / APP / Repeat
Aux2 (SAT- Cable	Yellow / YouTube / Repeat
Power AUX2	Shift + Power
Play/ Save AUX2	Shift + Play /
Pause AUX2	Shift + Pause / Step /
Stop AUX2	Shift + Stop /
Rec AUX2	Shift + Rec / Rec Mode
<</ Tuner -	Shift + << /
>>/ Tuner +	Shift + >> /
PR- / I << AUX2	Shift + I << / Preset-
PR+/ >>I AUX2	Shift + >>I / Preset+
Menu AUX2	Shift + Menu / Home

Original	Rechange
Up AUX2	Shift + Up
Left / RDS AUX2	Shift + Left
OK AUX2	Shift + OK
Right / PTY AUX2	Shift + Right
Clear AUX2	Shift + Exit / Cancel / Clear
Down AUX2	Shift + Down
Back/ St - Mono	Shift + Back / Return
PR+/ >>I AUX2	Shift + CH+ /
PR- / I << AUX2	Shift + CH- /
1 AUX2	Shift + 1
2 AUX2	Shift + 2
3 AUX2	Shift + 3
4 AUX2	Shift + 4
5 AUX2	Shift + 5
6 AUX2	Shift + 6
7 AUX2	Shift + 7
8 AUX2	Shift + 8

Original	Rechange	Original	Rechange
9 AUX2	SHIFT + 9		
Gui de AUX2	SHIFT + GUIDE EPG		
0 AUX2	SHIFT + 0		