Original		Rechange	
RECEIVER	Power Receiver		Power
ENTER	Enter Receiver	OK	Ok
	Up Receiver		Up
	Down Receiver		Down
	Right Receiver		Right
	Left Receiver		Left
RETURN	Return Receiver	RETURN BACK	Back
Q SETUP	Q/Setup Receiver	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
PLAY	Play Receiver	PLAY MODE	Play
	I << Receiver		I <<
	>>I Receiver		>>I
	<< Receiver		<<
	>> Receiver		>>
	Pause Receiver		Pause
	Stop Receiver		Stop
1	1 Receiver	1	1

Original		Rechange	
2	2 Receiver	2	2
3	3 Receiver	3	3
4	4 Receiver	4	4
5	5 Receiver	5	5
6	6 Receiver	6	6
7	7 Receiver	7	7
8	8 Receiver	8	8
9	9 Receiver	9	9
0 11	0/11 Receiver	0	0
D.TUN +10 DIMMER	+10/--/--10/Dimmer/D.Tun Receiver	SHIFT + GUIDE	Shift + Guide
CLR SLEEP 12	CLR/Sleep/12 Receiver	FAV PRE-CH	Pre Ch
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Receiver	B	Green
RANDOM GAME C	Game/Yellow/Random Receiver	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Receiver	D	Blue
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL –	Vol -

Original	Rechange	Original	Rechange
CH Disc/Album+ Receiver	Ch +	Yellow Tv	Subt
CH Disc/Album- Receiver	Ch -	Blue Tv	TV/R
Power Tv	Shift + Power	1 Tv	Shift + 1
Input Tv	AV	2 Tv	Shift + 2
CH+ Tv	Shift + Ch +	3 Tv	Shift + 3
CH- Tv	Shift + Ch -	4 Tv	Shift + 4
Up Tv	Shift + Up	5 Tv	Shift + 5
Enter Tv	Shift + Ok	6 Tv	Shift + 6
Down Tv	Shift + Down	7 Tv	Shift + 7
Right Tv	Shift + Right	8 Tv	Shift + 8
Left Tv	Shift + Left	9 Tv	Shift + 9
Menu/Prev CH	Menu	0/11 Tv	Shift + 0
Top Menu/Guide	Shift + Menu	+10/--/--10 Tv	Guide
Return Tv	Shift + Back	CLR/Sleep/12	Shift + Pre Ch
Q/Setup Tv	Shift + Smart	Vol + Tv	Shift + Dual
Red Tv	Options	Vol - Tv	Shift + Options
Green Tv	Dual	AUX	Text

Original		Rechange		Original	Rechange
TV/CD	TV/ CD	PICTURE FORMAT	Format		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shift + Subt		
NET	NET	SHIFT + APP MEDIA	Shift + Media		
PC	PC	SHIFT + SEARCH TV/R	Shift + TV/ R		
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shift + Text		
USB	USB	SHIFT + TIMER AV	Shift + AV		

Original		Rechange	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Rechange	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tun Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original		Rechange	
CBL/SAT	CBL/ SAT	REPEAT TEXT	Text
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL −	Vol -
SOURCE	Power CBL/ SAT	SHIFT +	Shi ft + Power
CH DISC	CH Di sc/ Al bum+ CBL/ SAT	+ CH	Ch +
ALBUM	CH Di sc/ Al bum- CBL/ SAT	CH −	Ch -
MENU PREV CH	Menu/ Prev CH CBL/ SAT	SHIFT + TOP MENU MENU	Shi ft + Menu
TOP MENU GUIDE	Top Menu/ Gui de CBL/ SAT	SHIFT + SETTINGS OPT	Shi ft + Opti ons
RETURN	Retur n CBL/ SAT	SHIFT + RETURN BACK	Shi ft + Back
Q SETUP	Q/ Set up	SHIFT + HOME SMART	Shi ft + Smart
	Up CBL/ SAT	SHIFT + ▲	Shi ft + Up
ENTER	Enter CBL/ SAT	SHIFT + OK	Shi ft + Ok
	Down CBL/ SAT	SHIFT + ▼	Shi ft + Down
	Ri ght CBL/ SAT	SHIFT + ▶	Shi ft + Ri ght
	Left CBL/ SAT	SHIFT + ◀	Shi ft + Left
II	Pause CBL/ SAT	SHIFT + II	Shi ft + Pause
■	Stop CBL/ SAT	SHIFT + ■	Shi ft + Stop

Original		Rechange	
◀◀	<< CBL/ SAT	SHIFT + CH −	Shi ft + Ch -
▶▶	>> CBL/ SAT	SHIFT + + CH	Shi ft + Ch +
PLAY	Pl ay CBL/ SAT	ECO 3D	3D
SEARCH MOVIE/TV A	Movi e Tv/ Red/ Search	SOUND DUAL	Dual
REPEAT MUSIC B	Musi c/ Green/ Repe at CBL/ SAT	AD SUBT	Subt
RANDOM GAME C	Game/ Yel l ow/ Ran dom CBL/ SAT	TIMER AV	AV
MODE STEREO D	St ereo/ Bl ue/ Mode CBL/ SAT	PICTURE FORMAT	For mat
1	1 CBL/ SAT	SHIFT + 1	Shi ft + 1
2	2 CBL/ SAT	SHIFT + 2	Shi ft + 2
3	3 CBL/ SAT	SHIFT + 3	Shi ft + 3
4	4 CBL/ SAT	SHIFT + 4	Shi ft + 4
5	5 CBL/ SAT	SHIFT + 5	Shi ft + 5
6	6 CBL/ SAT	SHIFT + 6	Shi ft + 6
7	7 CBL/ SAT	SHIFT + 7	Shi ft + 7
8	8 CBL/ SAT	SHIFT + 8	Shi ft + 8
9	9 CBL/ SAT	SHIFT + 9	Shi ft + 9
11 0	0/ 11 CBL/ SAT	SHIFT + 0	Shi ft + 0

Original	Rechange	Original	Rechange
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Original		Rechange	
SOURCE	Power TV/CD		Power
CH DISC	CH/Disc+ TV/CD	CH	Ch +
ALBUM	CH/Disc TV/CD	CH	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
PLAY	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause

Original		Rechange	
	Stop TV/CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

TV/CD

Original		Rechange		Original		Rechange	
VOL	Vol + Recei ver	+ VOL	Vol +				
VOL	Vol - Recei ver	VOL −	Vol -				
TV/CD	TV/ CD	SEARCH TV/R	TV/ R				

Original		Rechange	
RECEIVER	Power Receiver Zone 2		Power
VOL +	Vol + Zone 2	VOL +	Vol +
VOL -	Vol - Zone 2	VOL -	Vol -
CH DISC +	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM -	CH Disc/Album- Zone 2	CH -	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Rechange	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Original	Rechange	Original	Rechange
+10/- - /- - 10/D. Tu Dimmer Zone 2	Guide		
CLR/Sleep/12	Pre Ch		