Mandis shop

Sony RM-S171

Original		Rechange	
DSG	DSG	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
I/⏻	Power	⏻	Power
CD	Play CD	SLOW ▶	Play / Slow
	Pause CD	STEP-FREEZE ⏸	Pause / Step / Freeze
	Stop CD	HOLD ■	Stop / Hold
TUNER/BAND	Play	+ CH PAGE	CH+ / Page+
	I<<<- Tuner	PRESET- ⏮	I<<<- / Preset-
	I<<<- Tuner	SHIFT +	TUNE- ◀◀ Shift + <<<- /
	>>>I/+ Tuner	PRESET+ ⏭	>>>I / Preset+
	>>>I/+ Tuner	SHIFT +	TUNE+ ▶▶ Shift + >>>I/
TAPE	Play/<> Tape	SHIFT +	SLOW ▶ Shift + Play /
	<< Tape	TUNE- ◀◀	<< / Tune-
	>> Tape	TUNE+ ▶▶	>> / Tune+
DIR MODE	Play Dir Mode	CH PAGE −	CH- / Page-
FM MODE	FM Mode	ANGLE INFO	Info / Angle
REC	Rec	REC MODE ●	Rec / Rec Mode

Original		Rechange	
CD REPEAT	CD Repeat	APP REPEAT	Green / APP / Repeat
FUNCTION	Function	HOME MENU	Menu / Home
TUNING MODE PLAY MODE	Tuning Mode/Play Mode	LIST SMART	Smart / List
MEMORY	Up/Memory	▲	Up
TIMER SELECT	Right/Timer	▶	Right
VOL	Vol +	+ VOL	Vol +
TIMER SET	Left/Timer Set	◀	Left
ENTER ON/OFF	Enter/On/Off	OK	OK
SLEEP	Down/Sleep	▼	Down
SLEEP	Down/Sleep	TIMER SLEEP	Sleep / Timer
	Vol -	VOL −	Vol -

https://remotecontrols.fr/Sony/1363-564-telecommande-remplacement-pour-Sony-RM-S171-147291.htm