Original		Rechange	
	Power		Power
	TV Set Power	SHIFT +	Shift + Power
V+	TV Set V +	VOL +	Vol +
V-	TV Set V -	VOL −	Vol -
	Mute	MUTE	Mute
TV MODE	TV Mode	SETTINGS OPT	Options
TV/RAD	TV / Rad	SEARCH TV/R	TV/R
FIND	Find	APP MEDIA	Media
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9

Original		Rechange	
0	0	0	0
RECALL	Recall	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Right		Right
	Down		Down
	Left		Left
OK	OK	OK	Ok
SAT	Sat	TIMER AV	AV
FAV	Fav	FAV PRE-CH	Pre Ch
PG+	PG +	CH +	Ch +
PG-	PG -	CH −	Ch -
You Tube	YouTube	HOME SMART	Smart
	Play / Pauln fo	DISPLAY INFO	Info
EPG	EPG	GUIDE	Guide

Original		Rechange	
PLAY/PAUSE	Play / Pause	PLAY MODE	Play
PLAY/PAUSE	Play / Pause		Pause
FB	<< FB		<<
FF	>> FF		>>
STOP	Stop		Stop
PREV	I << Prev		I <<
NEXT	>>I Next		>>I
SLEEP	Sleep	PROG SLEEP	Sleep
SUB-T	Sub-T	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text
REC	Rec	REC MODE	Rec
IPTV	Red / IPTV	A	Red
VIDEO	Green / Video	B	Green
PVR	Yellow / PVR	C	Yellow
TIMER	Blue / Timer	D	Blue

Original	Rechange