Original		Rechange	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	[≡]	GOTO TEXT	Text / Goto
	0	HDMI - SAT 0	0
	←	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up

Original		Rechange	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
VOL▲	Vol +	+ VOL	Vol +
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
CH▲	CH +	+ CH PAGE	CH+ / Page+
VOL▼	Vol -	VOL −	Vol -
00:00	00:00	LIST SMART	Smart / List
CH▼	CH -	CH PAGE −	CH- / Page-
	[◄ ►]	SIZE ZOOM	Zoom / Size
	[_]	EQ SUBTITLE	Subtitle / EQ
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange		Original	Rechange
	▢/ ♪	PROGRAM TV/ RADIO	TV/ Radi o /		
	❤	PC FAV MARKER	Fav / Marker / PC		
	(i)	ANGLE INFO	I nf o / Angl e		