Original		Rechange	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
abc 2	2	2	2
def 3	3	3	3
ghi 4	4	4	4
jkl 5	5	5	5
mno 6	6	6	6
pqrs 7	7	7	7
tuv 8	8	8	8
wxyz 9	9	9	9
0	0	0	0
TEXT TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	Pre-Ch	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Rechange	
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
CH LIST	Ch List	DISC NAV LIST	List
CONTENT	Content	ZOOM	Eject
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN BACK	Return/Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	Ok	OK	Ok
A	Red	A	Red
B	Green	B	Green

Original		Rechange	
C	Yellow	C	Yellow
D	Blue	D	Blue
MEDIA.P	Media. P	APP MEDIA	Media
@TV INTERNET	Internet / Tv@	HOME SMART	Smart
I-II DUAL	Dual I - II	SOUND DUAL	Dual
D	D	ECO 3D	3D
P.SIZE	P. Size	PICTURE FORMAT	Format
SUBT.	Subt.	AD SUBT	Subt
<<	<<	<<	<<
Pause	Pause	Pause	Pause
>>	>>	>>	>>
Rec	Rec	REC MODE	Rec
Play	Play	PLAY MODE	Play
Stop	Stop	Stop	Stop

Original	Rechange