Original	Rechange
Power	Power
OSD	Display / Media
Open / Close	Eject / Surround
N/P	Picture / Format
Repeat	Green / APP / Repeat
A-B	Yellow / YouTube / Repeat
RAN	Smart / List
L/R	D.Menu / Top
Slow	Shift + Play /
Resume	Shift + Right
Step	Shift + Pause / Step /
Key+	CH+ / Page+
Return	Back / Return
3D	Shift + 3
Vol +	Vol +
Key-	CH- / Page-
Time	Sleep / Timer

Original	Rechange
PDVD	AV / Input / RDS
Vol -	Vol -
Language	Audio / Lang I/II
Subtitle	Subtitle / EQ
Angle	Info / Angle
Prog	TV/Radio /
Setup	Setup / OPT /
Up	Up
Title	Sound / Title
Left	Left
Enter	OK
Right	Right
Menu	Menu / Home
Down	Down
Zoom	Zoom / Size
Play	Play / Slow
Pause	Pause / Step / Freeze

Original		Rechange		Original		Rechange	
STOP	Stop	HOLD	Stop / Hold	FWD	>> FWD	TUNE+	>> / Tune+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
PREV	I << Prev	PRESET-	I << / Preset-				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
NEXT	>>I Next	PRESET+	>>I / Preset+				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
REV	<< REV	TUNE-	<< / Tune-				
10/0	10/0	HDMI - SAT 0	0				
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--				
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear				