# Mandis shop

R- 40A01

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | 1 | 1 | 1 |
| | 2 | 2 | 2 |
| | 3 | 3 | 3 |
| | 4 | 4 | 4 |
| | 5 | 5 | 5 |
| | 6 | 6 | 6 |
| | 7 | 7 | 7 |
| | 8 | 8 | 8 |
| | 9 | 9 | 9 |
| | 0 | 0 | 0 |
| | Source/[ ≡] | TIMER AV | AV |
| NORMAL/OK | Normal / OK/[ ≡i ] | OK | Ok |
| PR | PR+ | + CH | Ch + |
| PR | Up | | Up |
| PR | Down | | Down |
| PR | PR- | CH − | Ch - |

| Original | | Rechange | |
|---|---|---|---|
| | Right / [ ≡o] | | Right |
| | Vol + | + VOL | Vol + |
| | Vol - | VOL − | Vol - |
| | Left / [ ≡+] | | Left |
| | Menu | TOP MENU MENU | Menu |
| | Mute | MUTE | Mute |
| RECALL | Recall / [ ≡?] | FAV PRE-CH | Pre Ch |
| SLEEP | Sleep/ [ ≡♦] | PROG SLEEP | Sleep |
| SKIP | Red/ Skip | A | Red |
| MOVE | Green/ Movie | B | Green |
| DELETE | Yellow/ Delete | C | Yellow |
| MODE | Blue/ Mode | D | Blue |
| | [ ≡] | REPEAT TEXT | Text |
| | [ ≡x] | SEARCH TV/R | TV/ R |

https://remotecontrols.fr/Daewoo/1604-2350-telecommande-remplacement-pour-Daewoo-R40A01-R37A01.htm