Original		Rechange	
	Power Receiver		Power
	Display	DISPLAY INFO	Info
	BD / DVD	1	1
	VCR / DVR	2	2
	CBL / SAT	3	3
	GAME	4	4
	PC	5	5
	AUX	6	6
	TUNER	TIMER AV	AV
	TUNER	7	7
	TV / CD	8	8
	PHONO	9	9
	PORT	GUIDE	Guide
	NET	SHIFT + APP MEDIA	Shift + Media
	NET	0	0
	USB	APP MEDIA	Media
	USB	FAV PRE-CH	Pre Ch

Original		Rechange	
	Muting	MUTE	Mute
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Home	HOME SMART	Smart
	CH+	+ CH	Ch +
	CH-	CH −	Ch -
	SP Layout	E-MANUAL D.MENU	D. Menu
	Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
	Enter	OK	Ok
	Right		Right
	Down		Down
	Setup	SETTINGS OPT	Options
	Return	RETURN BACK	Back
	I<<	I<<	I<<
	>>I	>>I	>>I

Original		Rechange	
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Rev		Pause
	Stop		Stop
SEARCH MOVIE/TV	Movie / TV	A	Red
REPEAT MUSIC	Music	B	Green
RANDOM GAME	Game	C	Yellow
MODE THX	Thx	D	Blue
D.TUN +10 DIMMER	Dimmer	SOUND DUAL	Dual
D.TUN +10 DIMMER	D.TUN	SEARCH TV/R	TV/R
CLR SLEEP	Sleep	PROG SLEEP	Sleep
1	1	SHIFT + 1	Shift + 1
2	2	SHIFT + 2	Shift + 2
3	3	SHIFT + 3	Shift + 3
4	4	SHIFT + 4	Shift + 4
5	5	SHIFT + 5	Shift + 5

Original		Rechange	
6	6	SHIFT + 6	Shift + 6
7	7	SHIFT + 7	Shift + 7
8	8	SHIFT + 8	Shift + 8
9	9	SHIFT + 9	Shift + 9
0	0	SHIFT + 0	Shift + 0

Original		Rechange	
RECEIVER AMP	Power Receiver		Power
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	TIMER AV	AV
TUNER	TUNER	7	7
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
PORT	PORT	GUIDE	Guide
NET	NET	SHIFT + APP MEDIA	Shift + Media
NET	NET	0	0
USB	USB	APP MEDIA	Media
USB	USB	FAV PRE-CH	Pre Ch
MUTING	Muting	MUTE	Mute

Original		Rechange	
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
HOME	Home	HOME SMART	Smart
CH DISC +	CH+ / Album+	+ CH	Ch +
ALBUM -	CH- / Album-	CH -	Ch -
GUIDE/TOP MENU SP LAYOUT	Top Menu	E-MANUAL D.MENU	D. Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Page- / Playlis		Left
ENTER	Enter	OK	Ok
PLAYLIST	Page+ / Playlist		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I<<		I<<
	>>I		>>I
	<<		<<

Original		Rechange	
	Play	PLAY MODE	Play
	>>	>>	>>
	Pause		Pause
	Stop		Stop
SEARCH MOVIE/TV	Search	SEARCH TV/R	TV/R
SEARCH MOVIE/TV	Search	A	Red
REPEAT MUSIC	Repeat	B	Green
REPEAT MUSIC	Repeat	REPEAT TEXT	Text
RANDOM GAME	Random	C	Yellow
MODE THX	Mode	D	Blue
MODE THX	Mode	SHIFT + PLAY MODE	Shift + Play
1	1	SHIFT + 1	Shift + 1
2	2	SHIFT + 2	Shift + 2
3	3	SHIFT + 3	Shift + 3
4	4	SHIFT + 4	Shift + 4
5	5	SHIFT + 5	Shift + 5
6	6	SHIFT + 6	Shift + 6

Original		Rechange	
7	7	SHIFT + 7	Shift + 7
8	8	SHIFT + 8	Shift + 8
9	9	SHIFT + 9	Shift + 9
11 0	0	SHIFT + 0	Shift + 0
--/--- +10	--/--- +10	SHIFT + GUIDE	Shift + Guide
12 CLR SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
12 CLR SLEEP	CLR	CLEAR EXIT	Exit

Original		Rechange	
RECEIVER AMP	Power Receiver		Power
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	7	7
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
TUNER	TUNER	TIMER AV	AV
PORT	PORT	GUIDE	Guide
NET	NET	0	0
NET	NET	SHIFT + APP MEDIA	Shift + Media
USB	USB	FAV PRE-CH	Pre Ch
USB	USB	APP MEDIA	Media

Original		Rechange	
MUTING	Muting	MUTE	Mute
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL -	Vol -
HOME	Home	HOME SMART	Smart
CH DISC	CH+	+ CH	Ch +
ALBUM	CH-	CH -	Ch -
GUIDE/TOP MENU SP LAYOUT	SP Layout	SHIFT + TOP MENU MENU	Shift + Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Left		Left
ENTER	Enter	OK	Ok
PLAYLIST	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I<<		I<<
	>>I		>>I

Original		Rechange	
	<<		<<
	>>		>>
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
SEARCH MOVIE/TV	Movie / TV	A	Red
REPEAT MUSIC	Music	B	Green
RANDOM GAME	Game	C	Yellow
MODE THX	Thx	D	Blue
D.TUN +10 DIMMER	Dimmer	SOUND DUAL	Dual
D.TUN +10 DIMMER	D.TUN	SEARCH TV/R	TV/R
CLR SLEEP	Sleep	PROG SLEEP	Sleep
1	1	SHIFT + 1	Shift + 1
2	2	SHIFT + 2	Shift + 2
3	3	SHIFT + 3	Shift + 3
4	4	SHIFT + 4	Shift + 4
5	5	SHIFT + 5	Shift + 5

Original		Rechange	
6	6	SHIFT + 6	Shift + 6
7	7	SHIFT + 7	Shift + 7
8	8	SHIFT + 8	Shift + 8
9	9	SHIFT + 9	Shift + 9
11 0	0	SHIFT + 0	Shift + 0

Original		Rechange	
RECEIVER AMP	Power		Power
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	BD / DVD	1	1
VCR/DVR	VCR / DVR	2	2
CBL/SAT	CBL / SAT	3	3
GAME	GAME	4	4
PC	PC	5	5
AUX	AUX	6	6
TUNER	TUNER	7	7
TUNER	TUNER	TIMER AV	AV
TV/CD	TV / CD	8	8
PHONO	PHONO	9	9
PORT	PORT	-/-- GUIDE	Guide
NET	NET	0	0
NET	NET	SHIFT + APP MEDIA	Shift + Media
USB	USB	FAV PRE-CH	Pre Ch
USB	USB	APP MEDIA	Media

Original		Rechange	
MUTING	Muting	MUTE	Mute
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL -	Vol -
HOME	Home	HOME SMART	Smart
CH DISC	CH+	+ CH	Ch +
ALBUM	CH-	CH -	Ch -
GUIDE/TOP MENU SP LAYOUT	SP Layout	SHIFT + TOP MENU MENU	Shift + Menu
PREV CH/MENU VIDEO	Menu	TOP MENU MENU	Menu
	Up		Up
PLAYLIST	Left		Left
ENTER	Enter	OK	Ok
PLAYLIST	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	I<<	I<<	I<<
	>>I	>>I	>>I

Original	Rechange	Original	Rechange
<<	<<	6	SHIFT + 6 Shift + 6
>>	>>	7	SHIFT + 7 Shift + 7
Play	PLAY MODE Play	8	SHIFT + 8 Shift + 8
Pause	Pause	9	SHIFT + 9 Shift + 9
Stop	Stop	11 0	SHIFT + 0 Shift + 0
SEARCH MOVIE/TV Movie / TV	A Red		
REPEAT MUSIC Music	B Green		
RANDOM GAME Game	C Yellow		
MODE THX Thx	D Blue		
10 +10 D.TUN DIMMER Dimmer	SOUND DUAL Dual		
10 +10 D.TUN DIMMER D. TUN	SEARCH TV/R TV/R		
12 CLR SLEEP Sleep	PROG SLEEP Sleep		
1 1	SHIFT + 1 Shift + 1		
2 2	SHIFT + 2 Shift + 2		
3 3	SHIFT + 3 Shift + 3		
4 4	SHIFT + 4 Shift + 4		
5 5	SHIFT + 5 Shift + 5		