Original	Rechange	Original	Rechange
Power MD	Power	Right	Right
TV	TV/R	Left	Left
CD	Yellow	Enter	Ok
DVD	Blue	Menu	D. Menu
Tuner/Band	Green	Display	Info
Tape	Red	Top Menu/Disc/Deck	Menu
VCR	Smart	1 MD	1
MD	Media	2 MD	2
Vol +	Vol +	3 MD	3
Vol -	Vol -	4 MD	4
Muting	Mute	5 MD	5
Stop MD	Stop	6 MD	6
Play MD	Play	7 MD	7
<<|<< MD	<<	8 MD	8
>>|>> MD	>>	9 MD	9
Up	Up	0 MD	0
Down	Down	>10/-/-- MD	Guide

Original		Rechange	
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
⏻	Power TV	SHIFT + ⏻	Shift + Power
VOL ^	Tv Vol Up	SHIFT + + VOL	Shift + Vol +
TV VOL	Tv Vol Down	SHIFT + VOL −	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5

Original		Rechange	
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original	Rechange	Original	Rechange
Power DVD	Power	Right	Right
TV	TV/R	Left	Left
VCR	Smart	Enter	Ok
Tuner / Band	Green	Stereo	Dual
Tape	Red	Surround	Options
MD	Media	SFC	Subt
CD	Yellow	Test	Back
DVD	Blue	Delay	Format
Play DVD	Play	Level	3D
I <<< / << DVD	<<	+	Ch +
Stop DVD	Stop	-	Ch -
>>> / >>I DVD	>>	1 DVD	1
Top Menu/ Disc/ Deck	Menu	2 DVD	2
Display	Info	3 DVD	3
Menu	D. Menu	4 DVD	4
Up	Up	5 DVD	5
Down	Down	6 DVD	6

Original		Rechange	
7	7 DVD	7	7
8	8 DVD	8	8
9	9 DVD	9	9
0	0 DVD	0	0
≥10/-/--	>10/ - / - - DVD	GUIDE	Gui de
VOL +	Vol +	+ VOL	Vol +
– VOL	Vol -	VOL –	Vol -
MUTING	Mut i ng	MUTE	Mut e

Original	Rechange

Original		Rechange	
	Power CD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	CD	C	Yellow
	DVD	D	Blue
	Tape	A	Red
	MD	APP MEDIA	Media
	Tuner/Band	B	Green
	Stop CD		Stop
	I<<</<< CD	<<	<<
	>>/>>I CD	>>	>>
	Play CD	PLAY MODE	Play
	Menu	E-MANUAL D.MENU	D. Menu
	Display	DISPLAY INFO	Info
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Enter	OK	Ok
	Stereo	SOUND DUAL	Dual
	Surround	SETTINGS OPT	Options
	SFC	AD SUBT	Subt
	Test	RETURN BACK	Back
	Delay	PICTURE FORMAT	Format
	Level	ECO 3D	3D
	+	+ CH	Ch +
	-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play

Original	Rechange	Original	Rechange
I <<| << Tape	SHIFT + << Shift + <<		
>>| >>I Tape	SHIFT + >> Shift + >>		
Top Menu/ Disc/ Deck	SHIFT + TOP MENU MENU Shift + Menu		
1 CD- Tape	1 1		
2 CD- Tape	2 2		
3 CD- Tape	3 3		
4 CD- Tape	4 4		
5 CD- Tape	5 5		
6 CD- Tape	6 6		
7 CD- Tape	7 7		
8 CD- Tape	8 8		
9 CD- Tape	9 9		
0 CD- Tape	0 0		
>10/ - / - - CD- Tape	-/-- GUIDE Guide		
Direct Tuning/ Disc Ente	REPEAT TEXT Text		

Original		Rechange	
	Power VCR		Power
	VCR	HOME SMART	Smart
	Tape	A	Red
	TV	SEARCH TV/R	TV/R
	CD	C	Yellow
	DVD	D	Blue
	Tuner/Band	B	Green
	MD	APP MEDIA	Media
	Stop		Stop
	I<<<<	<<	<<
	>>>>I	>>	>>
	Play	PLAY MODE	Play
	1 VCR	1	1
	2 VCR	2	2
	3 VCR	3	3
	4 VCR	4	4
	5 VCR	5	5

Original		Rechange	
	6 VCR	6	6
	7 VCR	7	7
	8 VCR	8	8
	9 VCR	9	9
	0 VCR	0	0
	>10/-/-- VCR	-/-- GUIDE	Guide
	Direct Tuning/Disc Ente	REPEAT TEXT	Text
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Display	DISPLAY INFO	Info

Original		Rechange	
MENU	Menu	E-MANUAL D.MENU	D. Menu
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH −	Ch -
⏻	Power Tuner / Band	SHIFT + ⏻	Shift + Power
1	1 Tuner / Band	SHIFT + 1	Shift + 1
2	2 Tuner / Band	SHIFT + 2	Shift + 2
3	3 Tuner / Band	SHIFT + 3	Shift + 3
4	4 Tuner / Band	SHIFT + 4	Shift + 4
5	5 Tuner / Band	SHIFT + 5	Shift + 5
6	6 Tuner / Band	SHIFT + 6	Shift + 6
7	7 Tuner / Band	SHIFT + 7	Shift + 7

Original		Rechange	
8	8 Tuner / Band	SHIFT + 8	Shift + 8
9	9 Tuner / Band	SHIFT + 9	Shift + 9
0	0 Tuner / Band	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/--	SHIFT + -/-- GUIDE	Shift + Guide