Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
	(↔)	LANG I/II AUDIO	Audio / Lang I/II
TV	TV	PROGRAM TV/RADIO	TV/Radio /
	_/	TITLE SOUND	Sound / Title
	[#]→	FORMAT PICTURE	Picture / Format
	[.≡]	GOTO TEXT	Text / Goto
	[≡+]	SHIFT + HOLD	Shift + Stop /
	[≡♦]	SHIFT + SIZE ZOOM	Shift + Zoom /
	[≡x]◷	RETURN BACK	Back / Return
	[≡?][+]	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
	[≡i]	ANGLE INFO	Info / Angle
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Rechange	
6	6	TUNER 6	6
A/B	A/B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
OUTPUT	Output	RDS AV INPUT	AV / Input / RDS
	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
C	C	CLEAR EXIT CANCEL	Exit / Cancel / Clear
IN 123	IN 123	TOP MENU D.MENU	D.Menu / Top
1- TP OFF	1-/TP Off	PC FAV MARKER	Fav / Marker / PC
C00	C00	OPT-TOOLS SETUP	Setup / OPT /
2- TP ON	2-/TP On	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
	Vol+	+ VOL	Vol+
PROGR	Prog+	+ CH PAGE	CH+ / Page+
	Vol-	VOL −	Vol-
PROGR	Prog-	CH PAGE −	CH- / Page-

Original	Rechange
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
→>	Display / Media
-[<>]	Left
[<>]+	Right
♦	Zoom / Size
(*)	Menu / Home
→·←	Smart / List
[II··]	OK
[II··]+	Up
[...]	Subtitle / EQ
Contrast+	>>I / Preset+
Brightness+	Shift + Right
[II··]-	Down
Prog+ Down	Shift + CH+ / Page+

Original	Rechange
Contrast-	I<< / Preset-
Brightness-	Shift + Left
Power Down	Shift + Power
Prog- Down	Shift + CH- /
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Stop	Stop / Hold
Pause	Pause / Step / Freeze

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original		Rechange	
	Power Down		Power
	Prog+ Down		CH+ / Page+
	Prog- Down		CH- / Page-
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Rec		Rec / Rec Mode

Original	Rechange