Original		Rechange	
POWER	POWER	Power	Power
MUTE	MUTE	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
P. MODE	P. MODE	FORMAT PICTURE	Picture / Format
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
S. MODE	S. MODE	TITLE SOUND	Sound / Title
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SLEEP	SLEEP	TIMER SLEEP	Sleep / Timer
ASPECT	ASPECT	SHIFT + FORMAT PICTURE	Shift + Picture / Format
0	0	HDMI - SAT 0	0
BACK	BACK	RETURN BACK	Back / Return

Original		Rechange	
NICAM / A2	NICAM/A2	LANG I/II AUDIO	Audio / Lang I/II
INPUT	INPUT	RDS AV INPUT	AV / Input / RDS
UP			Up
DISPLAY	DISPLAY	MEDIA DISPLAY	Display / Media
LEFT			Left
OK	OK	OK	OK
RIGHT			Right
MENU	MENU	HOME MENU	Menu / Home
DOWN			Down
EXIT	EXIT	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RED		NETFLIX SEARCH	Red / Netflix / Search
GREEN		APP REPEAT	Green / APP / Repeat
YELLOW		YouTube REPEAT A-B	Yellow / YouTube / Repeat
BLUE		Prime Video RANDOM	Blue / Prime Video / Random
TEXT	TEXT	GOTO TEXT	Text / Goto
PLAY / PAUSE	TEXT	SLOW	Play / Slow
PLAY / PAUSE	TEXT	STEP - FREEZE	Pause / Step / Freeze

Original	Rechange	Original	Rechange
SIZE	SIZE ZOOM — Zoom / Size	REC. MENU	TOP MENU D.MENU — D. Menu / Top
STOP	HOLD — Stop / Hold	TV / RADIO	PROGRAM TV/RADIO — TV/ Radio /
HOLD	SHIFT + HOLD — Shift + Stop /	VOL-	VOL — Vol -
REW	TUNE- — << / Tune-	VOL+	VOL + — Vol +
FWD	TUNE+ — >> / Tune+	CH-	CH PAGE — CH- / Page-
INDEX	ANGLE INFO — Info / Angle	CH+	CH PAGE + — CH+ / Page+
REVEAL	OPT-TOOLS SETUP — Setup / OPT /		
SKIP PREV.	PRESET- — I<< / Preset-		
SUBPAGE	SURROUND — Eject / Surround		
SKIP NEXT	PRESET+ — >>I / Preset+		
REPEAT	SHIFT + APP REPEAT — Shift + Green / APP /		
SUBTITLE	EQ SUBTITLE — Subtitle / EQ		
AUTO	LIST SMART — Smart / List		
LANG.	SHIFT + LANG I/II AUDIO — Shift + Audio / Lang I/II		
FAV	PC FAV MARKER — Fav / Marker / PC		
T. SHIFT	SHIFT + STEP - FREEZE — Shift + Pause / Step /		
REC	REC MODE — Rec / Rec Mode		