Original		Rechange	
	Power		Power
PP	PP	RETURN BACK	Back / Return
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
--	--	-/-- GUIDE EPG	Guide / EPG / -/--
INFO	Info	ANGLE INFO	Info / Angle
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange	
	Up		Up
	P+	+ CH PAGE	CH+ / Page+
	Left		Left
M	M	OK	OK
M	M	HOME MENU	Menu / Home
	Right		Right
	Down		Down
	P-	CH PAGE −	CH- / Page-
V−	Vol -	VOL −	Vol -
V+	Vol +	+ VOL	Vol +
SOUND	Red/ Sound	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Red/ Sound	TITLE SOUND	Sound / Title
PICTURE	Green/ Picture	APP REPEAT	Green / APP / Repeat
PICTURE	Green/ Picture	FORMAT PICTURE	Picture / Format
FEATURE	Yellow/ Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INSTALL	Blue/ Install	Prime Video RANDOM	Blue / Prime Video / Random
TV	TV	MEDIA DISPLAY	Display / Media

Original	Rechange	Original	Rechange
AV	AV / Input / RDS		
[≡]	Text / Goto		
[/ ≡]	<< / Tune-		
[≡o]	Sleep / Timer		
[≡+]	Stop / Hold		
[≡x]	>> / Tune+		
[≡♦]	Zoom / Size		
[≡?]	Pause / Step / Freeze		
[≡i]	Play / Slow		