| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| PP | PP | RETURN BACK | Back / Return |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| P<P | P<P | PC FAV MARKER | Fav / Marker / PC |
| 0 | 0 | HDMI - SAT 0 | 0 |
| -- | -- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| INFO | Info | ANGLE INFO | Info / Angle |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II |

| Original | | Rechange | |
|---|---|---|---|
| | Up | | Up |
| | P+ | + CH PAGE | CH+ / Page+ |
| | Left | | Left |
| M | M | OK | OK |
| M | M | HOME MENU | Menu / Home |
| | Right | | Right |
| | Down | | Down |
| | P- | CH PAGE − | CH- / Page- |
| V− | Vol - | VOL − | Vol - |
| V+ | Vol + | + VOL | Vol + |
| SOUND | Red/ Sound | NETFLIX SEARCH | Red / Netflix / Search |
| SOUND | Red/ Sound | TITLE SOUND | Sound / Title |
| PICTURE | Green/ Picture | APP REPEAT | Green / APP / Repeat |
| PICTURE | Green/ Picture | FORMAT PICTURE | Picture / Format |
| FEATURE | Yellow/ Feature | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| INSTALL | Blue/ Install | Prime Video RANDOM | Blue / Prime Video / Random |
| TV | TV | MEDIA DISPLAY | Display / Media |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| AV | AV / Input / RDS | | |
| [ ≡] | Text / Goto | | |
| [ / ≡] | << / Tune- | | |
| [ ≡o] | Sleep / Timer | | |
| [ ≡+] | Stop / Hold | | |
| [ ≡x] | >> / Tune+ | | |
| [ ≡♦] | Zoom / Size | | |
| [ ≡?] | Pause / Step / Freeze | | |
| [ ≡i ] | Play / Slow | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |