Original		Rechange	
RECEIVER	Standby / On	Power	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
INPUT SE	INPUT PREV.	CH PAGE –	CH- / Page-
SELECT	INPUT NEXT	+ CH PAGE	CH+ / Page+
NETWORK	NETWORK	SHIFT + BLUETOOTH 9	Shift + 9
iPod/USB	iPod / USB	SHIFT + USB 8	Shift + 8
ADAPTER	ADAPTER	SHIFT + TAPE 5	Shift + 5
BD	BD	SHIFT + AUX - HDD 7	Shift + 7
DVD	DVD	SHIFT + DVD 2	Shift + 2
DVR/BDR	DVR / BDR	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
SAT/CBL	SAT / CBL	SHIFT + HDMI - SAT 0	Shift + 0
GAME	GAME	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
VIDEO	VIDEO	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD - STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
AUTO/ DIRECT	Auto / Direct	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange	
ALC/ STANDARD	ALC /	APP REPEAT	Green / APP / Repeat
ADV SURR	Adv. Surr.	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+Favorite	+ Favorite	PC FAV MARKER	Fav / Marker / PC
AUDIO PARAMETER	Audio	LANG I/II AUDIO	Audio / Lang I/II
TUNE	Up		Up
TUNE	Tune+	SHIFT + TUNE+	Shift + >> /
TOOLS MENU	Tools Menu	OPT-TOOLS SETUP	Setup / OPT /
VOLUME +	Volume+	+ VOL	Vol +
PRESET	Left		Left
PRESET	Preset -	SHIFT + PRESET-	Shift + I<< / Preset-
ENTER	Enter	OK	OK
PRESET	Right		Right
PRESET	Preset +	SHIFT + PRESET+	Shift + >>I / Preset+
TUNE	Down		Down
TUNE	Tune-	SHIFT + TUNE-	Shift + << /
–	Volume-	VOL –	Vol -
HOME MENU PTY iPod CTRL	Home Menu	HOME MENU	Menu / Home

Original		Rechange	
	i Pod Ctrl.	TOP MENU D.MENU	D. Menu / Top
	PTY	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
	Return	RETURN BACK	Back / Return
	BAND	PROGRAM TV/RADIO	TV/Radio /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Mute	DIMMER MUTE	Mute / Dimmer
	I <<	PRESET-	I << / Preset-
	BASS-	SHIFT +	Shift + Down
	>>I	PRESET+	>>I / Preset+
	BASS+	SHIFT +	Shift + Up
	<<	TUNE-	<< / Tune-
	TREBLE-	SHIFT +	Shift + Left
	>>	TUNE+	>> / Tune+
	TREBLE+	SHIFT +	Shift + Right
	1	TV 1	1

Original		Rechange	
	PHASE	SIZE ZOOM	Zoom / Size
	2	DVD 2	2
	3	CD-STB 3	3
	Signal Sel.	FORMAT PICTURE	Picture / Format
	DISP	MEDIA DISPLAY	Display / Media
	4	VIDEO 4	4
	S. Retriever	LIST SMART	Smart / List
	5	TAPE 5	5
	SB CH	GOTO TEXT	Text / Goto
	6	TUNER 6	6
	CHANNEL	SHIFT + LIST SMART	Shift + Smart / List
	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	7	AUX-HDD 7	7
	Midnight	EQ SUBTITLE	Subtitle / EQ
	Speakers	TITLE SOUND	Sound / Title
	8	USB 8	8
	9	BLUETOOTH 9	9

Original		Rechange		Original	Rechange
LEV + 9	CHANNEL LEVEL	SHIFT + CH PAGE +	Shift + CH+ /		
CH −	Shuffle	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		
DIMMER CLR +10	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
0	0	HDMI - SAT 0	0		
LEV − ENTER	CHANNEL LEVEL	SHIFT + CH PAGE −	Shift + CH- /		

Original	Rechange	Original	Rechange
Standby / On	Power	ALC /	Green / APP / Repeat
Sleep	Sleep / Timer	Adv. Surr.	Yellow / YouTube / Repeat
INPUT PREV.	CH- / Page-	+ Favorite	Fav / Marker / PC
INPUT NEXT	CH+ / Page+	Audio	Audio / Lang I/II
NETWORK	SHIFT + 9	Up	Up
iPod/USB	SHIFT + 8	Tune+	SHIFT + TUNE+ Shift + >> /
ADAPTER	SHIFT + 5	Tools Menu	Setup / OPT /
BD	SHIFT + 7	Volume+	Vol +
DVD	SHIFT + 2	Left	Left
DVR/BDR	SHIFT + FAV MARKER Shift + Fav / Marker / PC	Preset -	SHIFT + PRESET- Shift + I<< / Preset-
SAT/CBL	SHIFT + 0	Enter	OK
GAME	SHIFT + GUIDE EPG Shift + Guide / EPG / -/--	Right	Right
VIDEO	SHIFT + 4	Preset +	SHIFT + PRESET+ Shift + >>I / Preset+
CD	SHIFT + 3	Down	Down
TV	SHIFT + 1	Tune-	SHIFT + TUNE- Shift + << /
TUNER	SHIFT + 6	Volume-	Vol -
AUTO/ DIRECT	NETFLIX SEARCH Red / Netflix / Search	Home Menu	HOME MENU Menu / Home

Original		Rechange	
HOME MENU PTY iPod CTRL	iPod Ctrl.	TOP MENU D.MENU	D. Menu / Top
HOME MENU PTY iPod CTRL	PTY	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
RETURN BAND	Return	RETURN BACK	Back / Return
RETURN BAND	BAND	PROGRAM TV/RADIO	TV/Radio /
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
− BASS ⏮	I<<	PRESET− ⏮	I<< / Preset-
− BASS ⏮	BASS-	SHIFT + ▼	Shift + Down
BASS + ⏭	>>I	PRESET+ ⏭	>>I / Preset+
BASS + ⏭	BASS+	SHIFT + ▲	Shift + Up
− TRE ◀◀	<<	TUNE− ◀◀	<< / Tune-
− TRE ◀◀	TREBLE-	SHIFT + ◀	Shift + Left
TRE + ▶▶	>>	TUNE+ ▶▶	>> / Tune+
TRE + ▶▶	TREBLE+	SHIFT + ▶	Shift + Right
EQ 1	1	TV 1	1

Original		Rechange	
PHASE 2	2	DVD 2	2
PHASE 2	PHASE	SIZE ZOOM	Zoom / Size
SIGNAL SEL 3	3	CD-STB 3	3
SIGNAL SEL 3	Signal Sel.	FORMAT PICTURE	Picture / Format
DISP	DISP	MEDIA DISPLAY	Display / Media
S.RETRIEVER 4	4	VIDEO 4	4
S.RETRIEVER 4	S. Retriever	LIST SMART	Smart / List
SB CH 5	5	TAPE 5	5
SB CH 5	SB CH	GOTO TEXT	Text / Goto
CH SELECT 6	6	TUNER 6	6
CH SELECT 6	CHANNEL	SHIFT + LIST SMART	Shift + Smart / List
CH+	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
MIDNIGHT 7	7	AUX-HDD 7	7
MIDNIGHT 7	Midnight	EQ SUBTITLE	Subtitle / EQ
SPEAKERS 8	8	USB 8	8
SPEAKERS 8	Speakers	TITLE SOUND	Sound / Title
LEV + 9	9	BLUETOOTH 9	9

Original		Rechange		Original	Rechange
LEV + 9	CHANNEL	SHIFT + CH PAGE +	Shift + CH+ /		
CH −	Shuffle	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		
DIMMER CLR +10	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
0	0	HDMI - SAT 0	0		
LEV − ENTER	CHANNEL	SHIFT + CH PAGE −	Shift + CH- /		