| Original | Rechange |
|---|---|
| RECEIVER Power Receiver | Power |
| BD/DVD BD/DVD | SHIFT + DVD 2 Shift + 2 |
| CBL/SAT CBL/SAT | SHIFT + HDMI - SAT 0 Shift + 0 |
| GAME Game | SHIFT + BLUETOOTH 9 Shift + 9 |
| PC PC | SHIFT + PC FAV MARKER Shift + Fav / Marker / PC |
| AUX AUX | SHIFT + AUX - HDD 7 Shift + 7 |
| TUNER TUNER | SHIFT + TUNER 6 Shift + 6 |
| TV/CD TV/CD | SHIFT + CD - STB 3 Shift + 3 |
| PHONO Phono | SHIFT + VIDEO 4 Shift + 4 |
| NET NET | SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/-- |
| USB USB | SHIFT + USB 8 Shift + 8 |
| DISPLAY Display | MEDIA DISPLAY Display / Media |
| MUTING Muting | DIMMER MUTE Mute / Dimmer |
| CH DISC CH/Disc/Album | CH PAGE CH+ / Page+ |
| VOL Vol + | VOL Vol + |
| ALBUM CH/Disc/Album | CH PAGE CH- / Page- |
| VOL Vol - | VOL Vol - |

| Original | Rechange |
|---|---|
| Up | Up |
| PLAYLIST Left Playlist | Left |
| ENTER Enter | OK |
| PLAYLIST Right Playlis | Right |
| Q SETUP Q/Setup | OPT-TOOLS SETUP Setup / OPT / |
| Down | Down |
| RETURN Return | RETURN BACK Back / Return |
| AUDIO HOME Home/Audio | LANG I/II AUDIO Audio / Lang I/II |
| I<< | PRESET- I<< / Preset- |
| << | TUNE- << / Tune- |
| >> | TUNE+ >> / Tune+ |
| >>I | PRESET+ >>I / Preset+ |
| Pause | STEP - FREEZE Pause / Step / Freeze |
| Play | SLOW Play / Slow |
| Stop | HOLD Stop / Hold |
| SEARCH MOVIE/TV A Movie/Tv/Search/ | NETFLIX SEARCH Red / Netflix / Search |
| REPEAT MUSIC B Music/Repeat/B | APP REPEAT Green / APP / Repeat |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| RANDOM GAME C | Game/ Random/ | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| MODE STEREO D | Stereo/ Mode/ D | Prime Video RANDOM | Blue / Prime Video / Random | | |
| 1 | 1 | TV 1 | 1 | | |
| 2 | 2 | DVD 2 | 2 | | |
| 3 | 3 | CD - STB 3 | 3 | | |
| 4 | 4 | VIDEO 4 | 4 | | |
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| -/--- 10 +10 D.TUN DIMMER | +10/ - - / - - - 10/ Dimer/ D.Tun | -/-- GUIDE EPG | Guide / EPG / - / - - | | |
| 11 0 | 0/ 11 | HDMI - SAT 0 | 0 | | |
| 12 CLR SLEEP | CLR/ Sleep/ 12 | PC FAV MARKER | Fav / Marker / PC | | |
| 12 CLR SLEEP | CLR/ Sleep/ 12 | TIMER SLEEP | Sleep / Timer | | |
| 12 CLR SLEEP | CLR/ Sleep/ 12 | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| SOURCE | Power BD/DVD | | Power |
| | Play BD/DVD | SLOW | Play / Slow |
| | Pause BD/DVD | STEP-FREEZE | Pause / Step / Freeze |
| | Stop BD/DVD | HOLD | Stop / Hold |
| | << BD/DVD | TUNE- | << / Tune- |
| | >> BD/DVD | TUNE+ | >> / Tune+ |
| | I<< BD/DVD | PRESET- | I<< / Preset- |
| | >>I BD/DVD | PRESET+ | >>I / Preset+ |
| AUDIO HOME | Audio BD/DVD | LANG I/II AUDIO | Audio / Lang I/II |
| TOP MENU SP/GUIDE | Top Menu | TOP MENU D.MENU | D.Menu / Top |
| Q SETUP | Setup BD/DVD | OPT-TOOLS SETUP | Setup / OPT / |
| MENU PREV CH | Menu BD/DVD | HOME MENU | Menu / Home |
| | Up BD/DVD | | Up |
| PLAYLIST | Left BD/DVD | | Left |
| ENTER | Enter BD/DVD | OK | OK |
| PLAYLIST | Right BD/DVD | | Right |
| 12 CLR SLEEP | CLR/12 BD/DVD | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Rechange | |
|---|---|---|---|
| | Down BD/DVD | | Down |
| RETURN | Return BD/DVD | RETURN BACK | Back / Return |
| VOL | Vol + Receiver | + VOL | Vol + |
| BD/DVD | BD/DVD | LIST SMART | Smart / List |
| VOL | Vol - Receiver | VOL − | Vol - |
| CBL/SAT | CBL/SAT | MEDIA DISPLAY | Display / Media |
| 1 | 1 BD/DVD | TV 1 | 1 |
| 2 | 2 BD/DVD | DVD 2 | 2 |
| 3 | 3 BD/DVD | CD-STB 3 | 3 |
| 4 | 4 BD/DVD | VIDEO 4 | 4 |
| 5 | 5 BD/DVD | TAPE 5 | 5 |
| 6 | 6 BD/DVD | TUNER 6 | 6 |
| 7 | 7 BD/DVD | AUX-HDD 7 | 7 |
| 8 | 8 BD/DVD | USB 8 | 8 |
| 9 | 9 BD/DVD | BLUETOOTH 9 | 9 |
| 10 +10 D.TUN DIMMER | +10/--/--10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 11 0 | 0/11 BD/DVD | HDMI-SAT 0 | 0 |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| CLR/12 BD/DVD | Fav / Marker / PC | Down CBL/SAT | Shift + Down |
| Search BD/DVD | Red / Netflix / Search | Return CBL/SAT | Shift + Back / Return |
| Repeat BD/DVD | Green / APP / Repeat | CH Disc/Album+ CBL/SAT | Shift + CH+ / |
| Stereo/Mode | Yellow / YouTube / Repeat | CH Disc/Album CBL/SAT | Shift + CH- / |
| Random | Blue / Prime Video / Random | 1 CBL/SAT | Shift + 1 |
| Power CBL/SAT | Shift + Power | 2 CBL/SAT | Shift + 2 |
| Play CBL/SAT | Shift + Play / | 3 CBL/SAT | Shift + 3 |
| Pause CBL/SAT | Shift + Pause / Step / | 4 CBL/SAT | Shift + 4 |
| Stop CBL/SAT | Shift + Stop / | 5 CBL/SAT | Shift + 5 |
| << CBL/SAT | Shift + << / | 6 CBL/SAT | Shift + 6 |
| >> CBL/SAT | Shift + >> / | 7 CBL/SAT | Shift + 7 |
| Setup CBL/SAT | Shift + Setup / OPT / Tools | 8 CBL/SAT | Shift + 8 |
| Menu/Prev CH CBL/SAT | Shift + Menu / | 9 CBL/SAT | Shift + 9 |
| Up CBL/SAT | Shift + Up | Guide CBL/SAT | Shift + Guide / EPG / -/-- |
| Left CBL/SAT | Shift + Left | 0/11 CBL/SAT | Shift + 0 |
| Enter CBL/SAT | Shift + OK | Movie Tv/Search CBL/SAT | Shift + Red / Netflix / |
| Right CBL/SAT | Shift + Right | Music/Repeat CBL/SAT | Shift + Green / APP / Repeat |

| Original | | Rechange | | | Original | Rechange |
|---|---|---|---|---|---|---|
| RANDOM GAME C | Game/ Random | SHIFT | + | YouTube REPEAT A-B | Shift + Yellow / YouTube / | |
| MODE STEREO D | Stereo/ Mode | SHIFT | + | Prime Video RANDOM | Shift + Blue / Prime | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| SOURCE | Power CD | | Power |
| | Play CD | SLOW | Play / Slow |
| | Pause CD | STEP-FREEZE | Pause / Step / Freeze |
| | Stop CD | HOLD | Stop / Hold |
| | << CD | TUNE- | << / Tune- |
| | >> CD | TUNE+ | >> / Tune+ |
| | I<< CD | PRESET- | I<< / Preset- |
| | >>I CD | PRESET+ | >>I / Preset+ |
| AUDIO HOME | Audio CD | LANG I/II AUDIO | Audio / Lang I/II |
| SETUP | Setup CD | OPT-TOOLS SETUP | Setup / OPT / |
| | Up CD | | Up |
| PLAYLIST | Left CD | | Left |
| ENTER | Enter CD | OK | OK |
| PLAYLIST | Right CD | | Right |
| | Down CD | | Down |
| RETURN | Return CD | RETURN BACK | Back / Return |
| VOL | Vol + Receiver | VOL | Vol + |

| Original | | Rechange | |
|---|---|---|---|
| TV/CD | TV/CD | LIST SMART | Smart / List |
| CH DISC | CH/Disc+ CD | CH PAGE | CH+ / Page+ |
| VOL | Vol - Receiver | VOL | Vol - |
| ALBUM | CH/Disc- CD | CH PAGE | CH- / Page- |
| 1 | 1 CD | TV 1 | 1 |
| 2 | 2 CD | DVD 2 | 2 |
| 3 | 3 CD | CD-STB 3 | 3 |
| 4 | 4 CD | VIDEO 4 | 4 |
| 5 | 5 CD | TAPE 5 | 5 |
| 6 | 6 CD | TUNER 6 | 6 |
| 7 | 7 CD | AUX-HDD 7 | 7 |
| 8 | 8 CD | USB 8 | 8 |
| 9 | 9 CD | BLUETOOTH 9 | 9 |
| 10 +10 D.TUN DIMMER | +10/--/--10/D.Tu Dimmer CD | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 11 0 | 0/11 CD | HDMI-SAT 0 | 0 |
| 12 CLR SLEEP | CLR/Sleep/12 | PC FAV MARKER | Fav / Marker / PC |
| SEARCH MOVIE/TV A | Search CD | NETFLIX SEARCH | Red / Netflix / Search |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| REPEAT MUSIC B Repeat CD | APP REPEAT Green / APP / Repeat | | |
| MODE STEREO D Mode CD | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| RANDOM GAME C Random CD | Prime Video RANDOM Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Rechange | |
|---|---|---|---|
| RECEIVER | Power Receiver Zone 2 | | Power |
| CH DISC | CH Disc/Album+ Zone 2 | CH PAGE | CH+ / Page+ |
| VOL | Vol + Zone 2 | VOL | Vol + |
| ALBUM | CH Disc/Album Zone 2 | CH PAGE | CH- / Page- |
| VOL | Vol - Zone 2 | VOL | Vol - |
| | Up Zone 2 | | Up |
| PLAYLIST | Left Zone 2 | | Left |
| ENTER | Enter Zone 2 | OK | OK |
| PLAYLIST | Right Zone 2 | | Right |
| SETUP | Setup Zone 2 | OPT-TOOLS SETUP | Setup / OPT / |
| | Down Zone 2 | | Down |
| RETURN | Return Zone 2 | RETURN BACK | Back / Return |
| AUDIO HOME | Audio Zone 2 | LANG I/II AUDIO | Audio / Lang I/II |
| | I<< Zone 2 | PRESET- | I<< / Preset- |
| | >>I Zone 2 | PRESET+ | >>I / Preset+ |
| | << Zone 2 | TUNE- | << / Tune- |
| | Play Zone 2 | SLOW | Play / Slow |

| Original | | Rechange | |
|---|---|---|---|
| | >> Zone 2 | TUNE+ | >> / Tune+ |
| | Pause Zone 2 | STEP-FREEZE | Pause / Step / Freeze |
| | Stop Zone 2 | HOLD | Stop / Hold |
| SEARCH MOVIE/TV A | Movie Tv Zone | NETFLIX SEARCH | Red / Netflix / Search |
| REPEAT MUSIC B | Music Zone 2 | APP REPEAT | Green / APP / Repeat |
| RANDOM GAME C | Game Zone 2 | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| MODE STEREO D | Stereo Zone 2 | Prime Video RANDOM | Blue / Prime Video / Random |
| 1 | 1 Zone 2 | TV 1 | 1 |
| 2 | 2 Zone 2 | DVD 2 | 2 |
| 3 | 3 Zone 2 | CD-STB 3 | 3 |
| 4 | 4 Zone 2 | VIDEO 4 | 4 |
| 5 | 5 Zone 2 | TAPE 5 | 5 |
| 6 | 6 Zone 2 | TUNER 6 | 6 |
| 7 | 7 Zone 2 | AUX-HDD 7 | 7 |
| 8 | 8 Zone 2 | USB 8 | 8 |
| 9 | 9 Zone 2 | BLUETOOTH 9 | 9 |
| +10 D.TUN DIMMER | +10/--/--10/D.Tu Dimmer Zone 2 | -/-- GUIDE EPG | Guide / EPG / -/-- |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 0 / 11 | Zone 2 | 0 | 0 | | |
| CLR / Sleep / 12 | | FAV MARKER | Fav / Marker / PC | | |