Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
	Red	A	Red
	Green/ Mouse	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
INDEX	<</ Index	<<	<<
HOLD	>>/ Hold	>>	>>
SIZE	I <</ Size	I <<	I <<
SUBPAGE	>>I / Subpage	>>I	>>I
	Play	PLAY MODE	Play
	Pause	II	Pause
	Stop		Stop
NICAM/A2	Nicam/ A2	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
TXT	TXT	REPEAT TEXT	Text
CANCEL	Cancel	APP MEDIA	Media

Original		Rechange	
REVEAL	Reveal	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
TV/RADIO	Tv/ Radio	SEARCH TV/R	TV/ R
FAV	FAV	FAV PRE-CH	Pre Ch
	Nothing 1	E-MANUAL D.MENU	D. Menu
SLEEP	Sleep	PROG SLEEP	Sleep
DISP	Disp	DISPLAY INFO	Info
INPUT	Input	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -

Original		Rechange	
	Home	HOME SMART	Smart
CH.L	CH. L	DISC NAV LIST	List
CH	CH+	+ CH	Ch +
CH	CH-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Nothing 2	ZOOM	Eject
	Recall	RETURN BACK	Back
PICTURE	Picture	SHIFT + PICTURE FORMAT	Shift + Format

Original		Rechange	
ASPECT	Aspect	PICTURE FORMAT	Format
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual