Original		Rechange	
	Power		Power
USB	USB	TIMER AV	AV
CLOCK	Clock	ECO 3D	3D
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	APP MEDIA	Media
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	SETTINGS OPT	Options
	>>		>>
	>>		Up
	I <		I <<
	I <		Left
	Play/Pause	OK	Ok
	Play/Pause	PLAY MODE	Play
	Play/Pause		Pause
	>I		>>I
	>I		Right
	<<		<<

Original		Rechange	
	<<		Down
PROG	Prog	SHIFT + PROG SLEEP	Shift + Sleep
DISPLAY	Display	DISPLAY INFO	Info
ALB/ PRESET +	Alb/Preset +	+ CH	Ch +
ALB/ PRESET -	Alb/Preset -	CH -	Ch -
	Stop		Stop
MUTE	Mute	MUTE	Mute
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
DSC	DSC	A	Red
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
RDS	RDS	AD SUBT	Subt
DBB	DBB	D	Blue

Original		Rechange	
	Power		Power
	Play/ Pause	PLAY MODE	Play
	Play/ Pause	OK	Ok
	Play/ Pause		Pause
	Stop		Stop
	>>		>>
	>>		Up
	<<		<<
	>I		>>I
	<<		Down
	>I		Right
	I<		I<<
	I<		Left
MUTE	Mute	MUTE	Mute
SHUFFLE	Shuffle	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
DISPLAY	Display	DISPLAY INFO	Info

Original		Rechange	
PROG	Prog	PROG SLEEP	Sleep

Original		Rechange	
	Power		Power
	Play/ Pause	PLAY MODE	Play
	Play/ Pause	OK	Ok
	Play/ Pause		Pause
	Stop		Stop
	>>		>>
	>>		Up
	<<		<<
	>I		>>I
	<<		Down
	>I		Right
	I<		I<<
	I<		Left
ALB/ PRESET +	ALB/ Preset +	CH +	Ch +
ALB/ PRESET −	ALB/ Preset -	CH −	Ch -
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	SETTINGS OPT	Options

Original		Rechange	
PROG	Prog	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info

Original		Rechange		Original	Rechange
	Power		Power		
REPEAT	Repeat	REPEAT TEXT	Text		
SHUFFLE	Shuffle	SETTINGS OPT	Options		
	Play/ Pause	PLAY MODE	Play		
	Play/ Pause	OK	Ok		
	Pause		Pause		
	Stop		Stop		
ALB/ PRESET +	ALB/ Preset +	+ CH	Ch +		
ALB/ PRESET −	ALB/ Preset -	CH −	Ch -		
	>I		>>I		
	>I		Right		
	I<		I<<		
	I<		Left		
	<<		<<		
	<<		Down		
	>>		>>		
	>>		Up		