Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	PIP		Info / Angle
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Rechange	
	i / OSD		Display / Media
	Z / Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red / Image / I>		Red / Netflix / Search
	Green / Timer		Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	Play / Slow		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i / OSD		Display / Media

Original		Rechange	
	Disc Menu		D.Menu / Top
	Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Picture		Picture / Format
	Red/Picture		Red / Netflix / Search

Original	Rechange	Original	Rechange
Green / Timer	Sleep / Timer		
Play	Play / Slow		
Green / Timer	Green / APP / Repeat		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Sound / Title		
Stop	Stop / Hold		
Blue/Sound	Blue / Prime Video / Random		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Rechange	
	i / OSD		Display / Media
	Z / Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red / Image / I>		Red / Netflix / Search
	Red / Image / I>		Shift + Play / Slow

Original	Rechange	Original	Rechange
Green/Timer	Green / APP / Repeat		
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original		Rechange		Original		Rechange	
	Power		Power	Disc Menu	Z/Disc Menu	HOME MENU	Menu / Home
	1	TV 1	1		P+	CH PAGE +	CH+ / Page+
ABC	2	DVD 2	2		Up		Up
DEF	3	CD - STB 3	3		Left		Left
Audio PIP	PIP/Audio	LANG I/II AUDIO	Audio / Lang I/II		Vol -	VOL −	Vol -
GHI	4	VIDEO 4	4	OK	OK	OK	OK
JKL	5	TAPE 5	5		Right		Right
MNO	6	TUNER 6	6		Vol +	VOL +	Vol +
	[<>]	SIZE ZOOM	Zoom / Size	TXT	TXT	GOTO TEXT	Text / Goto
PQRS	7	AUX - HDD 7	7	TXT	<<	TUNE-	<< / Tune-
TUV	8	USB 8	8		P-	CH PAGE −	CH- / Page-
WXYZ	9	BLUETOOTH 9	9		Down		Down
	?	LIST SMART	Smart / List	TV-G	TV-G	-/-- GUIDE EPG	Guide / EPG / -/--
	I<	PRESET-	I<< / Preset-	TV-G	>>	TUNE+	>> / Tune+
	>I	PRESET+	>>I / Preset+		Red/Image/I>	FORMAT PICTURE	Picture / Format
	0	HDMI - SAT 0	0		Red/Image/I>	NETFLIX SEARCH	Red / Netflix / Search
OSD	i/OSD	MEDIA DISPLAY	Display / Media		Green/Timer	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		