Mandis shop

# Sony RM-SC55

| Original | | Rechange | |
|---|---|---|---|
| I / ⏻ | Power | | Power |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| TUNER MEMORY | Tuner Memory | SIZE ZOOM | Zoom / Size |
| PLAY MODE/ TUNING MODE | Play Mode/Tuning Mode | PROGRAM TV/ RADIO | TV/Radio / |
| Folder- | Folder- | CH PAGE − | CH- / Page- |
| REPEAT/ FM MODE | Repeat/FM | FORMAT PICTURE | Picture / Format |
| SELECT | Clock/Timer | | Up |
| SET | Clock/Timer Set | | Down |
| AUDIO IN | Audio In | LANG I/II AUDIO | Audio / Lang I/II |
| CD | CD | CD - STB 3 | 3 |
| TUNER BAND | Band/Tuner | SHIFT + PROGRAM TV/ RADIO | Shift + TV/Radio / Program |
| FUNCTION | Function | TOP MENU D.MENU | D.Menu / Top |
| I<<- | I<<- | PRESET- | I<< / Preset- |
| >>I+ | >>I+ | PRESET+ | >>I / Preset+ |
| <<← | <<← | TUNE- | << / Tune- |
| >>→ | >>→ | TUNE+ | >> / Tune+ |

| Original | | Rechange | |
|---|---|---|---|
| | Play | SLOW | Play / Slow |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| EQ | EQ | EQ SUBTITLE | Subtitle / EQ |
| VOLUME + | Vol+ | + VOL | Vol+ |
| VOLUME − | Vol- | VOL − | Vol- |
| ENTER | Enter | OK | OK |
| DISC SKIP | Disck Skip | PC FAV MARKER | Fav / Marker / PC |
| Folder+ | Folder+ | + CH PAGE | CH+ / Page+ |

https://remote-controls.ch/fr/Sony/1065500-79577-telecommande-de-remplacement-pour-Sony-RM-SC55-A1169936A.html