Original		Rechange	
	Power		Power
	e/ Energy Savi ng	SHIFT +	OK Shi ft + OK
	AV Mode	GOTO TEXT	Text / Goto
	I nput	RDS AV INPUT	AV / I nput / RDS
	TV	PROGRAM TV/ RADIO	TV/ Radi o /
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI - SAT 0	0
	Li st	LIST SMART	Smart / List
	Q. Vi ew	OPT-TOOLS SETUP	Set up / OPT / Tool s

Original		Rechange	
	FAV/ Mar k	PC FAV MARKER	Fav / Marker / PC
	Rati o	FORMAT PICTURE	Pi cture / Format
	Mut e/ Del et e	DIMMER MUTE	Mut e / Di mmer
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	CH+	CH PAGE +	CH+ / Page+
	CH-	CH PAGE −	CH- / Page-
	Menu	HOME MENU	Menu / Home
	Net cast	MEDIA DISPLAY	Di spl ay / Medi a
	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
	Down		Down
	Left		Left
	Ri ght		Ri ght
	Ent er	OK	OK
	Back	RETURN BACK	Back / Retur n
	Si mpl i nk	SIZE ZOOM	Zoom / Si ze

Original		Rechange		Original	Rechange
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
■	Stop	HOLD ■	Stop / Hold		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		