Mandis shop

RM- SCEX1

Original	Rechange
Power	Power
Play CD	Play / Slow
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I<<| -	I<< / Preset-
>>I / +	>>I / Preset+
Stereo/Mono	Audio / Lang I/II
Open/Close	Eject / Surround
Tuning Mode	Picture / Format
Tuner/Band	TV/Radio /
Function	Menu / Home
Up/Memory	Up
Left/Timer Set	Left
Enter/On/Off	OK
Right/Timer Select	Right

Original	Rechange
Down/Sleep	Down
Vol +	Vol +
DSG	Smart / List
Vol -	Vol -
Display	Display / Media
Repeat	Green / APP / Repeat
Play Mode	Blue / Prime Video / Random
Surround	Shift + Eject / Surround

https://remotes.fr/Sony/1065-574-telecommande-remplacement-pour-Sony-RM-SCEX1.htm