Original		Rechange	
ZONE OFF	Zone Off	SHIFT + Power	Shift + Power
ZONE ON	Zone On	Power	Power
(DVD) 1	Quick Select 1 (DVD)	TV 1	1
(SAT/CBL) 2	Quick Select 2 (SAT/CBL)	DVD 2	2
(VCR/iPod) 3	Quick Select 3 (VCR/iPod)	CD-STB 3	3
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV	TV	SHIFT + TV 1	Shift + 1
iPod	iPod	-/-- GUIDE EPG	Guide / EPG / -/--
HDP	HDP	AUX-HDD 7	7
NET/USB	Net/USB	USB 8	8
SAT/CBL	SAT/CBL	BLUETOOTH 9	9
VCR	VCR	VIDEO 4	4
DVR	DVR	TOP MENU D.MENU	D.Menu / Top
V.AUX	V.AUX	PC FAV MARKER	Fav / Marker / PC
TUNER	Tuner	TUNER 6	6
SAT TU	SAT TU	HDMI-SAT 0	0
DTU	DTU	TAPE 5	5

Original		Rechange	
CD	CD	SHIFT + CD-STB 3	Shift + 3
PHONO	Phono	LIST SMART	Smart / List
M.ZONE CALL	M.Zone Call	MEDIA DISPLAY	Display / Media
CH +	CH+	CH PAGE +	CH+ / Page+
SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
VOL +	Vol +	VOL +	Vol +
CH −	CH-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL −	Vol -	VOL −	Vol -
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
MEMORY	Memory	ANGLE INFO	Info / Angle
◄	Left	◄	Left
ENTER	Enter	OK	OK
►	Right	►	Right
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
▼	Down	▼	Down

Original		Rechange		Original	Rechange
RETURN	Return	RETURN BACK	Back / Return		
TUNING▼	I <<</ Tuning-	PRESET-	I << / Preset-		
TUNING▲	>>I / Tuning+	PRESET+	>>I / Preset+		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
USB	USB Direct Pla	PROGRAM TV/RADIO	TV/Radio /		
ALL MUSIC /FAVORITES	All	LANG I/II AUDIO	Audio / Lang I/II		

Original		Rechange		Original		Rechange	
ZONE OFF	Zone Off	SHIFT + Power	Shift + Power	CD	CD	SHIFT + CD-STB 3	Shift + 3
ZONE ON	Zone On	Power	Power	PHONO	Phono	LIST SMART	Smart / List
(DVD) 1	Quick Select 1 (DVD)	TV 1	1	M.ZONE CALL	M Zone Call	MEDIA DISPLAY	Display / Media
(SAT/CBL) 2	Quick Select 2 (SAT/CBL)	DVD 2	2	CH +	CH+	CH PAGE +	CH+ / Page+
(VCR / iPod) 3	Quick Select 3 (VCR/iPod)	CD-STB 3	3	SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
DVD	DVD	SHIFT + DVD 2	Shift + 2	VOL +	Vol +	VOL +	Vol +
TV	TV	SHIFT + TV 1	Shift + 1	CH –	CH-	CH PAGE –	CH- / Page-
iPod	iPod	-/-- GUIDE EPG	Guide / EPG / -/--	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HDP	HDP	AUX-HDD 7	7	VOL –	Vol -	VOL –	Vol -
NET/USB	NET/USB	USB 8	8	MENU	Menu	HOME MENU	Menu / Home
SAT/CBL	SAT/CBL	BLUETOOTH 9	9	▲	Up	▲	Up
VCR	VCR	VIDEO 4	4	MEMORY	Memory	ANGLE INFO	Info / Angle
DVR	DVR	TOP MENU D.MENU	D.Menu / Top	◄	Left	◄	Left
V.AUX	V.AUX	PC FAV MARKER	Fav / Marker / PC	ENTER	Enter	OK	OK
TUNER	Tuner	TUNER 6	6	►	Right	►	Right
SAT TU	SAT TU	HDMI-SAT 0	0	SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
DTU	DTU	TAPE 5	5	▼	Down	▼	Down

Original		Rechange		Original	Rechange
RETURN	Return	RETURN BACK	Back / Return		
TUNING▼	I <<</ Tuning-	PRESET-	I << / Preset-		
TUNING▲	>>I / Tuning+	PRESET+	>>I / Preset+		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
USB	USB Direct Pla	PROGRAM TV/RADIO	TV/Radio /		
ALL MUSIC /FAVORITES	All	LANG I/II AUDIO	Audio / Lang I/II		

Original		Rechange		Original		Rechange	
ZONE OFF	Zone Off	SHIFT + Power	Shift + Power	CD	CD	SHIFT + CD-STB 3	Shift + 3
ZONE ON	Zone On	Power	Power	PHONO	Phono	LIST SMART	Smart / List
(DVD) 1	Quick Select 1 (DVD)	TV 1	1	M.ZONE CALL	M Zone Call	MEDIA DISPLAY	Display / Media
(SAT/CBL) 2	Quick Select 2 (SAT/CBL)	DVD 2	2	CH +	CH+	CH PAGE +	CH+ / Page+
(VCR / iPod) 3	Quick Select 3 (VCR/iPod)	CD-STB 3	3	SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
DVD	DVD	SHIFT + DVD 2	Shift + 2	VOL +	Vol +	VOL +	Vol +
TV	TV	SHIFT + TV 1	Shift + 1	CH –	CH-	CH PAGE –	CH- / Page-
iPod	iPod	-/-- GUIDE EPG	Guide / EPG / -/--	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HDP	HDP	AUX-HDD 7	7	VOL –	Vol -	VOL –	Vol -
NET/USB	NET/USB	USB 8	8	MENU	Menu	HOME MENU	Menu / Home
SAT/CBL	SAT/CBL	BLUETOOTH 9	9	▲	Up	▲	Up
VCR	VCR	VIDEO 4	4	MEMORY	Memory	ANGLE INFO	Info / Angle
DVR	DVR	TOP MENU D.MENU	D.Menu / Top	◄	Left	◄	Left
V.AUX	V.AUX	PC FAV MARKER	Fav / Marker / PC	ENTER	Enter	OK	OK
TUNER	Tuner	TUNER 6	6	►	Right	►	Right
SAT TU	SAT TU	HDMI-SAT 0	0	SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
DTU	DTU	TAPE 5	5	▼	Down	▼	Down

Original		Rechange		Original	Rechange
RETURN	Return	RETURN BACK	Back / Return		
TUNING▼	I <</ Tuning-	PRESET-	I << / Preset-		
TUNING▲	>>I / Tuning+	PRESET+	>>I / Preset+		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
USB	USB Direct Pla	PROGRAM TV/RADIO	TV/Radio /		
ALL MUSIC /FAVORITES	All	LANG I/II AUDIO	Audio / Lang I/II		

Original		Rechange		Original		Rechange	
ZONE OFF	Zone Off	SHIFT +	Shift + Power	CD	CD	SHIFT + CD-STB 3	Shift + 3
ZONE ON	Zone On		Power	PHONO	Phono	LIST SMART	Smart / List
(DVD) 1	Quick Select 1 (DVD)	TV 1	1	M.ZONE CALL	M Zone Call	MEDIA DISPLAY	Display / Media
(SAT/CBL) 2	Quick Select 2 (SAT/CBL)	DVD 2	2	CH +	CH+	CH PAGE +	CH+ / Page+
(VCR / iPod) 3	Quick Select 3 (VCR/iPod)	CD-STB 3	3	SHIFT	Shift	OPT-TOOLS SETUP	Setup / OPT /
DVD	DVD	SHIFT +	Shift + 2	VOL +	Vol +	VOL +	Vol +
TV	TV	SHIFT +	Shift + 1	CH –	CH-	CH PAGE –	CH- / Page-
iPod	iPod	-/-- GUIDE EPG	Guide / EPG / -/--	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HDP	HDP	AUX-HDD 7	7	VOL –	Vol -	VOL –	Vol -
NET/USB	NET/USB	USB 8	8	MEMORY	Memory	ANGLE INFO	Info / Angle
SAT/CBL	SAT/CBL	BLUETOOTH 9	9	SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
VCR	VCR	VIDEO 4	4	TUNING▼	I<</Tuning-	PRESET-	I<< / Preset-
DVR	DVR	TOP MENU D.MENU	D.Menu / Top	TUNING▲	>>I/Tuning+	PRESET+	>>I / Preset+
V.AUX	V.AUX	PC FAV MARKER	Fav / Marker / PC		Stop	HOLD	Stop / Hold
TUNER	Tuner	TUNER 6	6		Play	SLOW	Play / Slow
SAT TU	SAT TU	HDMI-SAT 0	0		Pause	STEP-FREEZE	Pause / Step / Freeze
DTU	DTU	TAPE 5	5	REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Rechange		Original	Rechange
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
USB	USB Direct Pla	PROGRAM TV/RADIO	TV/Radio /		
ALL MUSIC /FAVORITES	All	LANG I/II AUDIO	Audio / Lang I/II		