Original		Rechange	
	Power		Power
	Direct Tv Rec	PROGRAM TV/RADIO	TV/Radio /
	Tv Aspect	SIZE ZOOM	Zoom / Size
	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
	Tracking/V-Lock+	CH PAGE +	CH+ / Page+
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Tracking/V-Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Volume+	VOL +	Vol +
	AV/Input Selec	AV INPUT RDS	AV / Input / RDS

Original		Rechange	
0	0	HDMI-SAT 0	0
-/--	-/--	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
	Volume-	VOL −	Vol -
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
SV/V+	SV/V+	FORMAT PICTURE	Picture / Format
STILL ALBUM	Still Album	OPT-TOOLS SETUP	Setup / OPT /
REPLAY	Replay	MEDIA DISPLAY	Display / Media
	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME	<<	TUNE-	<< / Tune-
INPUT SELECT AV	Left		Left

Original		Rechange	
OK	OK	OK	OK
Right	Right	Right	Right
>>	>> / Tune+	TUNE+	>> / Tune+
Down	Down	Down	Down
Stop	Stop / Hold	HOLD	Stop / Hold
Prog/Check	Shift + CH+ /	SHIFT + CH PAGE	Shift + CH+ /
Date+/Green	Shift + 2	SHIFT + DVD 2	Shift + 2
On+/Yellow	Shift + 3	SHIFT + CD-STB 3	Shift + 3
Off+/Blue	Shift + 7	SHIFT + AUX-HDD 7	Shift + 7
Prog/Check	Shift + CH+ /	SHIFT + CH PAGE	Shift + CH+ /
Date-	Shift + 5	SHIFT + TAPE 5	Shift + 5
On-	Shift + 6	SHIFT + TUNER 6	Shift + 6
Off-	Guide / EPG / -/--	-/-- GUIDE EPG	Guide / EPG / -/--
Reset	Back / Return	RETURN BACK	Back / Return
Cancel	Shift + Exit / Cancel / Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SP/LP/EP	Subtitle / EQ	EQ SUBTITLE	Subtitle / EQ
Timer	Sleep / Timer	TIMER SLEEP	Sleep / Timer

Original		Rechange	
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
OSD/DISPLAY	OSD Display	ANGLE INFO	Info / Angle
AV LINK	AV Link	LIST SMART	Smart / List

Original		Rechange	
	Power		Power
DIRECT TV REC	Direct Tv Rec	PROGRAM TV/RADIO	TV/Radio /
TV ASPECT	Tv Aspect	SIZE ZOOM	Zoom / Size
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
TRACKING/V-LOCK+	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Tracking/V-Lock-	CH PAGE -	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Volume+	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS

Original		Rechange	
0	0	HDMI-SAT 0	0
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Volume-	VOL -	Vol -
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
SV/V+	SV/V+	FORMAT PICTURE	Picture / Format
STILL ALBUM	Still Album	OPT-TOOLS SETUP	Setup / OPT /
REPLAY	Replay	MEDIA DISPLAY	Display / Media
	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	<<	TUNE-	<< / Tune-
	Left		Left

Original		Rechange	
OK	OK	OK	OK
Right	Right	Right	Right
>>	>> / Tune+	TUNE+	>> / Tune+
Down	Down	Down	Down
Stop	Stop / Hold	HOLD	Stop / Hold
Prog/Check	Shift + CH+ /	SHIFT + CH PAGE +	Shift + CH+ /
Date+/Green	Shift + 2	SHIFT + DVD 2	Shift + 2
On+/Yellow	Shift + 3	SHIFT + CD-STB 3	Shift + 3
Off+/Blue	Shift + 7	SHIFT + AUX-HDD 7	Shift + 7
Prog/Check	Shift + CH+ /	SHIFT + CH PAGE −	Shift + CH+ /
Date-	Shift + 5	SHIFT + TAPE 5	Shift + 5
On-	Shift + 6	SHIFT + TUNER 6	Shift + 6
Off-	Guide / EPG / -/--	-/-- GUIDE EPG	Guide / EPG / -/--
Reset	Back / Return	RETURN BACK	Back / Return
Cancel	Shift + Exit / Cancel / Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SP/LP/EP	Subtitle / EQ	EQ SUBTITLE	Subtitle / EQ
Timer	Sleep / Timer	TIMER SLEEP	Sleep / Timer

Original		Rechange	
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
OSD/DISPLAY	OSD Display	ANGLE INFO	Info / Angle
AV LINK	AV Link	LIST SMART	Smart / List

Original		Rechange	
	Power		Power
DIRECT TV REC	Direct Tv Rec	PROGRAM TV/RADIO	TV/Radio /
TV ASPECT	Tv Aspect	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
VOLUME +	Volume+	+ VOL	Vol +
TRACKING/V-LOCK	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
	Volume-	VOL −	Vol -
	Tracking/V-Lock-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Rechange	
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
	Red	NETFLIX SEARCH	Red / Netflix / Search
+ DATE	Green	APP REPEAT	Green / APP / Repeat
+ ON	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+ OFF	Blue	Prime Video RANDOM	Blue / Prime Video / Random