Original		Rechange	
Power		Power	
Sleep		Sleep / Timer	
Top Menu		Sound / Title	
Subtitle		Subtitle / EQ	
Display		Display / Media	
Setup		Setup / OPT /	
1		1	
2		2	
3		3	
Disc		Red / Netflix / Search	
4		4	
5		5	
6		6	
>10/-/--		Guide / EPG / -/--	
7		7	
8		8	
9		9	

Original		Rechange	
0		0	
Menu		Menu / Home	
EQ		Shift + Subtitle / EQ	
Up		Up	
Return		Back / Return	
Left		Left	
Enter		OK	
Right		Right	
Marker		Fav / Marker / PC	
3D AI		TV/Radio /	
Down		Down	
Angle		Info / Angle	
AV Effect		AV / Input / RDS	
Prologic		Zoom / Size	
CH Select		Green / APP / Repeat	
Test		Text / Goto	
Digital S.Woofer		Blue / Prime Video / Random	

Original		Rechange		Original		Rechange	
SUPER SRND	Super SRND	SURROUND	Eject / Surround	SKIP	Skip >>I	PRESET+	>>I / Preset+
VCR(EXT)/ VDP(AUX)	VCR(EXT) / VDP(AU	SHIFT + VIDEO 4	Shift + 4	VOL -	Vol -	VOL -	Vol -
TAPE / DECK 1/2	Tape/Deck 1/2	SHIFT + TAPE 5	Shift + 5	VOL +	Vol +	VOL +	Vol +
DVD	DVD	SHIFT + DVD 2	Shift + 2				
TUNER/ BAND	Tuner/Band	SHIFT + TUNER 6	Shift + 6				
CANCEL PLAY MODE	Play Mode	LIST SMART	Smart / List				
CANCEL PLAY MODE	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
◀/II	◁ Pause	STEP-FREEZE II	Pause / Step / Freeze				
■	Stop	HOLD ■	Stop / Hold				
▶	Play	SLOW ▶	Play / Slow				
MIX 2CH AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				
MIX 2CH AUDIO	Mix 2CH	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
SLOW/SE	<< Slow/Search	TUNE- ◀◀	<< / Tune-				
/SEARCH ▶▶	Slow/Search >>	TUNE+ ▶▶	>> / Tune+				
SHIFT	Shift	REC MODE ●	Rec / Rec Mode				
MUTING	Muting	DIMMER MUTE	Mute / Dimmer				
SKIP	I<< Skip	PRESET-	I<< / Preset-				