Mandis shop

VibroShaper VIBROSHAPER

Original		Rechange	
	Power		Power
	I >		Play / Slow
	I >		Pause / Step / Freeze
	Vel + / Speed+		Up
	TPO- / Time-		Left
	TPO+ / Time+		Right
	Vel - / Speed-		Down
	M		Menu / Home
	P		Info / Angle

Original	Rechange

https://remotes.fr/VibroShaper/1664-369-telecommande-remplacement-pour-VibroShaper-VibroShaper.htm