Original	Rechange	Original	Rechange
Display	Display / Media	System Off 5	5
Input Setup	Setup / OPT /	Device On AMP/ PROC/ Phono/	Power
Speaker Setup	Menu / Home	Device Off AMP	Shift + Power
Level Settings	Back / Return	System On PROC	6
Enter	OK	System ON Phono	7
Up	Up	System On TV 2	8
Down	Down	System On Tape	9
Right	Right	System On Tape	0
Left	Left	System On AUX	Smart / List
Volume+	Vol +	System ON CDR	Shift + Display / Media
Volume-	Vol -	System ON CDR	Shift + Smart / List
Mute	Mute / Dimmer		
EQ Preset	Subtitle / EQ		
System Off 1	1		
System Off 2	2		
System Off 3	3		
System OFF 4	4		

Original	Rechange	Original	Rechange
Device On 1	SHIFT + TV 1 Shift + 1	Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear
Device On 2	SHIFT + DVD 2 Shift + 2	Check	FORMAT PICTURE Picture / Format
Device On 3	SHIFT + CD-STB 3 Shift + 3	Prog	PROGRAM TV/RADIO TV/Radio /
Device Off	Power	Input Setup	OPT-TOOLS SETUP Setup / OPT /
Info/RDS	ANGLE INFO Info / Angle	Level Settings	RETURN BACK Back / Return
Time	TIMER SLEEP Sleep / Timer	Enter	OK OK
Display	MEDIA DISPLAY Display / Media	EQ Preset	EQ SUBTITLE Subtitle / EQ
1	TV 1 1	Speaker Setup	HOME MENU Menu / Home
2	DVD 2 2	Up	Up
3	CD-STB 3 3	Down	Down
4	VIDEO 4 4	Right	Right
5	TAPE 5 5	Left	Left
6	TUNER 6 6	Volume+	VOL + Vol +
7	AUX-HDD 7 7	Volume-	VOL - Vol -
8	USB 8 8	Pause	STEP-FREEZE Pause / Step / Freeze
9	BLUETOOTH 9 9	Mute	DIMMER MUTE Mute / Dimmer
0	HDMI-SAT 0 0	<<	TUNE- << / Tune-

Original		Rechange		Original		Rechange	
	>>	TUNE+	>> / Tune+				
I<<	I <<	PRESET-	I << / Preset-				
STOP	Stop	HOLD	Stop / Hold				
PLAY	Play	SLOW	Play / Slow				
>>I	>>I	PRESET+	>>I / Preset+				
+10	+10	PC FAV MARKER	Fav / Marker / PC				
FOLDER+	Folder+	CH+ PAGE	CH+ / Page+				
FOLDER-	Folder-	CH- PAGE	CH- / Page-				
REP A-B	Rep A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat				
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround				
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random				
-10	-10	-/-- GUIDE EPG	Guide / EPG / -/--				

Original	Rechange	Original	Rechange
Device On 1	SHIFT + TV 1 — Shift + 1	FM Mode	SIZE ZOOM — Zoom / Size
Device On 2	SHIFT + DVD 2 — Shift + 2	Auto	NETFLIX SEARCH — Red / Netflix / Search
Device On 3	SHIFT + CD-STB 3 — Shift + 3	Mem	Prime Video RANDOM — Blue / Prime Video / Random
Device Off	Power	Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear
Info/RDS	ANGLE INFO — Info / Angle	Volume+	+ VOL — Vol +
Display	MEDIA DISPLAY — Display / Media	Volume-	VOL — — Vol -
1	TV 1 — 1	Scroll +	+ CH PAGE — CH+ / Page+
2	DVD 2 — 2	Scroll -	CH PAGE — — CH- / Page-
3	CD-STB 3 — 3	Up	Up
4	VIDEO 4 — 4	Down	Down
5	TAPE 5 — 5	Right	Right
6	TUNER 6 — 6	Left	Left
7	AUX-HDD 7 — 7	Enter	OK — OK
8	USB 8 — 8	Mute	DIMMER MUTE — Mute / Dimmer
9	BLUETOOTH 9 — 9	Speaker Setup	HOME MENU — Menu / Home
0	HDMI-SAT 0 — 0	Select	GOTO TEXT — Text / Goto
Band	PROGRAM TV/RADIO — TV/Radio / Program	Input Setup	OPT-TOOLS SETUP — Setup / OPT / Tools

Original	Rechange	Original	Rechange
Level Settings	Back / Return		
EQ Preset	Subtitle / EQ		